



## **5G CPE**

### **UF51**

User Guide



## Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- ❖ The device must not be disassembled or remodeled in any way.
- ❖ To avoid risk of fire and electric shock, do not connect device to power supply or other devices when installing.
- ❖ In outdoor applications, please install the device under thunder lightning rod and add lightning arrseters.
- ❖ Do not place the device where the temperature or humidity is below/above the operating range.
- ❖ The device must never be subjected to drops, shocks or impacts.
- ❖ Make sure the device is firmly fixed when installing.


© 2011-2023 Xiamen Milesight IoT Co., Ltd.

### All rights reserved.

All information in this user guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.

## Declaration of Conformity

UF51 is in conformity with the essential requirements and other relevant provisions of the CE and RoHS.



For assistance, please contact  
Milesight technical support:  
Email: [iot.support@milesight.com](mailto:iot.support@milesight.com)  
Support Portal: [support.milesight-iot.com](http://support.milesight-iot.com)  
Tel: 86-592-5085280  
Fax: 86-592-5023065

Address: Building C09, Software Park III,  
Xiamen 361024, China

## Revision History

Date	Doc Version	Description
Jan. 19, 2023	V 2.0	Initial version

# Contents

Chapter 1 Product Introduction .....	5
1.1 Overview .....	5
1.2 Advantages .....	5
Chapter 2 Hardware Introduction .....	7
2.1 Packing List .....	7
2.2 Hardware Overview .....	7
2.3 Serial & IO & Power Pinouts .....	8
2.4 LED Indicators .....	8
2.5 Reset Button .....	9
2.6 Dimensions (mm) .....	9
Chapter 3 Power Supply .....	9
Chapter 4 Hardware Installation .....	10
4.1 SIM Installation .....	10
4.2 Waterproof Cover & Ethernet Cable Installation .....	10
4.3 Device Installation .....	11
4.3.1 Desktop .....	11
4.3.2 Wall Mounting .....	11
4.3.3 Pole Mounting .....	12
Chapter 5 Access to Web GUI .....	13
Chapter 6 Application Examples .....	14
6.1 Configure Cellular Connection .....	14
6.2 Configure Ethernet Connection .....	17
6.3 Configure Wi-Fi Access Point .....	19
6.4 Configure PPTP Client .....	20
6.5 Configure NAT Rule .....	22
6.6 Configure Serial DTU Connection .....	23
6.7 Restore Factory Defaults .....	25
6.8 Firmware Upgrade .....	26
Chapter 7 Web Configuration .....	27
7.1 Status .....	27
7.1.1 Overview .....	27
7.1.2 Cellular .....	29
7.1.3 GPS .....	31
7.1.4 Firewall .....	32
7.1.5 Routing Table .....	33
7.1.6 VPN .....	34
7.2 Network .....	35
7.2.1 Interfaces .....	35
7.2.1.1 WAN .....	35
7.2.1.2 LAN/DHCP Server .....	38
7.2.1.3 Cellular .....	40
7.2.1.4 Interface Settings .....	41

7.2.1.5 Link Failover .....	42
7.2.1.6 Static IP Address Assignment .....	44
7.2.2 WLAN (Wi-Fi Version Only) .....	44
7.2.3 Firewall .....	45
7.2.3.1 General Settings .....	45
7.2.3.2 ACL .....	47
7.2.3.3 Port Mapping (DNAT) .....	48
7.2.3.4 DMZ .....	49
7.2.3.5 Custom Rules .....	50
7.2.3.6 Certificates .....	50
7.2.4 Static Routes .....	50
7.2.5 Diagnostics .....	51
7.3 VPN .....	52
7.3.1 OpenVPN .....	52
7.3.1.1 OpenVPN Server .....	52
7.3.1.2 OpenVPN Client .....	55
7.3.2 IPsec .....	58
7.3.2.1 IPsec Server .....	58
7.3.2.2 IPsec Client .....	61
7.3.3 L2TP .....	64
7.3.4 PPTP .....	66
7.4 Industrial Interface .....	68
7.4.1 Serial Port .....	68
7.4.2 I/O .....	71
7.4.2.1 DI .....	71
7.4.2.2 DO .....	72
7.4.3 Modbus Master .....	72
7.4.3.1 Modbus Master .....	73
7.4.3.2 Channel .....	73
7.4.4 GPS .....	74
7.4.4.1 GPS IP Forwarding .....	75
7.4.4.2 GPS Serial Forwarding .....	76
7.5 System .....	77
7.5.1 System .....	78
7.5.2 Password .....	79
7.5.3 Device Management .....	79
7.5.3.1 Device Management .....	79
7.5.3.2 Cloud VPN .....	80
7.5.4 Backup / Upgrade .....	81
7.5.5 Reboot .....	82
7.5.6 Log .....	82
7.5.7 Debugger .....	83
7.5.7.1 Cellular Debugger .....	83
7.5.7.2 Firewall Debugger .....	84


## Chapter 1 Product Introduction

### 1.1 Overview

UF51 5G CPE is dedicated to cost effective solutions for 5G wireless networking applications. Adopting a high-performance and low power consumption industrial platform of quad-core CPU and 5G cellular module, UF51 supports the global WCDMA, 4G LTE, 5G Sub-6 GHz and NSA network and WiFi-6, to provide ultra-fast network to ensure the extremely safe and reliable connection to the wireless network. With IP67 waterproof enclosure, various kinds of installation methods, and authentic design, UF51 is competent to both indoor and outdoor applications.

Meanwhile, UF51 also supports 2-port Gigabit Ethernet switch, RS232/RS485 serial ports and Digital input/Digital output, which enable to scale up M2M applications combining data collection and high-speed transmission in a limited time and budget.

UF51 is particularly suitable for smart offices, video surveillance, digital media implementations, industrial automation, traffic applications, robots and so on.



### 1.2 Advantages

#### Fast & Reliable Network

- Industrial-grade quad-core CPU ARM Cortex-A55 processor, providing with high performance for data transmission
- Global 5G NSA/SA/4G LTE network for backup among multiple carrier networks
- Dual carrier aggregation (2CC CA) is supported in the 5G Sub-6GHz frequency band, with wider signal coverage superb
- Plug& play, supply lightning transmission via Gigabit Ethernet ports via Gigabit Ethernet ports or USB Type-C interface

- Support Wi-Fi 6, allows 2.4G & 5G dual band concurrent connections up to 3.6 Gbps download speed
- Embedded eight 5G antennas and four Wi-Fi antennas for best signal reception

### **Security & Reliability**

- Automated failover/failback backup among Ethernet, Cellular and Wi-Fi
- Secure transmission with VPN tunnels such as IPsec/OpenVPN/L2TP/PPTP
- Embeds hardware watchdog to automatically recover from various failures, ensure the highest level of availability
- Equipped with multiple security protection measures such as ACL, DMZ, SYN-Flood protection, and data filtering to ensure that the network is secured
- Support policy routing and NAT for more secure intranet access

### **Easy Maintenance**


- Milesight DeviceHub provides easy setup, mass configuration, and centralized management of remote devices
- The user-friendly web interface design and more than one option of upgrade help administrators to manage the device as easy as pie
- Support multilevel user authorities for security management

### **Robust Hardware Design**


- Equipped with I/O, serial port, and GPS for industrial transmission applications
- Wide operating temperature range from -30°C to 60°C and industrial design for harsh environments
- IP67 waterproof and UV-protective enclosure for outdoor applications
- PoE, DC or USB power supply optional
- Equipped with a vent plug to prevent condensation in the enclosure
- Pole mounting, wall mounting, desktop, bottom screw mounting for various applications
- 3-year warranty included

## Chapter 2 Hardware Introduction


### 2.1 Packing List




1 ×  
UF51 Device




1 ×  
Power Adapter



1 × Rubber Feet




1 × 8-pin Serial & IO &  
Power Terminal Block




1 × Bottom Cover  
with Cable Grand



1 × Waterproof  
Rubber Ring



1 × Mounting Bracket



4 × Wall Mounting  
Kits



2 × Hose Clamp




1 × Quick Start Guide



1 × Warranty Card


**!** If any of the above items is missing or damaged, please contact your sales representative.

### 2.2 Hardware Overview




① LED Indicator Area  
STATUS: Power & System Indicator  
5G: Cellular Indicator

② Waterproof Connector



- ③ SIM Slot
- ④ Reset Button
- ⑤ USB Type-C Port
- ⑥ Vent Plug
- ⑦ LAN2 Port
- ⑧ Bracket Mounting Screws
- ⑨ Serial & IO Power Interface
- ⑩ LAN1/WAN Port (PoE PD)

### 2.3 Serial & IO & Power Pinouts



PIN	RS232 /RS485	DI	DO	Power	Description
1	---	IN	---	---	Digital Input
2	GND	GND	---	---	Ground
3	---	---	---	(-)	Negative
4	---	---	---	(+)	Positive (9-48V)
5	---	---	COM	---	Common Ground
6	---	---	OUT	---	Digital Output
7	RXD/B	---	---	---	RS232-RXD RS485-B
8	TXD/A	---	---	---	RS232-TXD RS485-A

### 2.4 LED Indicators

LED	Indication	Status	Description
STATUS	Power & System Status	Off	The power is switched off
		Orange	Static: The system is startup
		Green	Static: The system is running properly
		Red	Static: The system goes wrong
5G	Cellular Status	Off	SIM card is registering or fails to register (or there are no SIM cards inserted)
		Green	Blinking rapidly: SIM card has been registered and is dialing up now
			Static: SIM card has been registered and dialed up to 5G network
Orange	Static: SIM card has been registered and dialed up		




			to 5G network
Ethernet Port	Link Indicator (Orange)	Off	Disconnected or connect failure
		On	Connected
		Blinking	Transmitting data
	Rate Indicator (Green)	Off	100 Mbps mode
		On	1000 Mbps mode

## 2.5 Reset Button

Function	Description	
	STATUS & 5G	Action
Reset	Static	Press and hold the reset button for more than 5 seconds.
	Static → Blinking	Release the button and wait.
	Off → Static Green	The device resets to factory default.

## 2.6 Dimensions (mm)



## Chapter 3 Power Supply

UF51 can be powered by 802.3af standard PoE or 9-48V DC. **Both power supplies can't be used at the same time.**

**PoE Supply:** provide power supply via PoE injector as follows. Besides, it can also be powered by PoE switch.




**DC Supply:** Connect the DC power cable to terminal block, then connect the terminal block to DC interface to power the device.

## Chapter 4 Hardware Installation

### 4.1 SIM Installation


Insert the SIM card into the device according to the direction icon on the device. If you need to take out the SIM card, press into the SIM card tray and it will pop out automatically.




### 4.2 Waterproof Cover & Ethernet Cable Installation

Please use round Ethernet cable and install as follows if UF51 needs to be placed outdoors:


1. Install the rubber ring into the bottom of the device. Note that the round part needs to face the gap of bottom when installing, otherwise it may cause waterlogged.




2. Connect a round Ethernet cable to LAN1/WAN port, then pass the Ethernet cable through the bottom cover and all parts of the cable gland.



3. Fix the bottom cover to the bottom of the device with 4 screws. Note the arrow behind the cover need to face the bracket mounting screws.



**Note:** Bottom cover can be fixed with the device via the wiring behind the cover.




## 4.3 Device Installation

UF51 supports multiple installation methods like desktop, wall mounting, pole mounting, etc. Before you start, make sure that all fittings have been installed.

**Note:** Do not connect device to power supply or other devices when installing.

### 4.3.1 Desktop

When using indoors, pile 4 rubber feet into the gaps at the bottom of the device. The rough surface of rubber feet should face desktop.



### 4.3.2 Wall Mounting

**Preparation:** mounting bracket(with 2 screws), wall plugs, wall mounting screws and other required tools.


A. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

**Note:** The connecting lines of adjacent points are at right angles.


B. Drill four holes with a depth of 32 mm by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.

C. Insert four wall plugs into the holes respectively.

D. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.




E. Hang the device to the mounting bracket via bracket mounting screws on the back of device, then screw the 2 bracket screws to the bottom of the device.




### 4.3.3 Pole Mounting

**Preparation:** mounting bracket(with 2 screws), hose clamps and other required tools.

- A. Loosen the hose clamp by turning the locking mechanism counter-clockwise.
- B. Straighten out the hose clamp and slide it through the rectangular rings in the mounting bracket, wrap the hose clamp around the pole.
- C. Use a screwdriver to tighten the locking mechanism by turning it clockwise.



D. Hang the device to the mounting bracket via bracket mounting screws on the back of device, then screw the 2 bracket screws to the bottom of the device.



## Chapter 5 Access to Web GUI

UF51 provides user-friendly web GUI for configuration and users can access it via LAN port. This chapter explains how to access to Web GUI of the UF51 router.


Username: **admin**

Password: **password**


IP Address: **192.168.1.1**

Connect PC to any LAN port of UF51 directly. The following steps are based on Windows 10 operating system for your reference.

1. Go to **Control Panel** → **Network and Internet** → **Network and Sharing Center**, then click **Ethernet** (It may have different names).




2. Go to **Properties** → **Internet Protocol Version 4(TCP/IPv4)**, select **"Obtain an IP address automatically"** or **"Use the following IP address"**, then assign a static IP manually within the same subnet of the device.




3. Open a Web browser on your PC (Chrome is recommended), type in the IP address 192.168.1.1 to

access the web GUI, then enter the default username and password, and click **Login**.



**!** If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

4. After you login the Web GUI, you can view system information and perform configuration on the router.

The screenshot displays the Milesight web GUI interface. At the top, there is a yellow banner with the text "For your device security, please change the default password!". Below this, the "Status" page is visible. The left sidebar contains a navigation menu with options like Overview, Cellular, GPS, Firewall, Routing Table, VPN, Network, VPN, Industrial, and System. The main content area shows system information in a table format, including Hostname (Router), Model (UF51-504AE-W), SN (6905C1715396), Firmware Version (78.0.0.2-a1), Hardware Version (V1.0), Local Time (2022-12-13 06:57:27), Uptime (6d 16h 22m 18s), and Average Load (2.01, 2.05, 2.00). Below the system information, there are two memory usage bar charts: "Available Memory" (421.84 MB / 651.02 MB (65%) used) and "Remaining Memory" (229.18 MB / 651.02 MB (35%) used). At the bottom, the "Current Network" section shows a WAN interface with a static IP address of 192.168.40.48.

## Chapter 6 Application Examples

### 6.1 Configure Cellular Connection

1. Ensure the SIM card is inserted well and all cellular antennas are connected to the correct connectors.
2. Go to **Network > Interface > Interface** page, find the cellular interface and click **Edit** button.

3. Fill in the necessary info of SIM card, then save all settings.

IP Type

APN

PIN

Authentication Type

Network Type

Roaming

MTU

Data Limit  MB

Billing Day

For 5G connection, you can choose specific bands to ensure high network speed.

Cellular Band

5G NR Band:  
N1, N3, N5, N7, N8, N20, N28, N38, N40, N41, N77, N78

LTE Band:  
B1, B3, B5, B7, B8, B20, B28, B32, B38, B40, B41, B42, B43

Search

- 5G NR Band
- N1
- N3
- N5
- N7

4. Go to **Network > Interface > Link Failover** to enable corresponding SIM rule and drag the buttons to change link priority.

- Click **Edit** of a link to configure ICMP ping detection information. When ping probe is enabled, the router will send ICMP packets to detection server to check if this link is valid. If no response and exceeding max retries, it will switch to the lower priority link.

**Note:** if you use private SIM card, please change a private server address or disable the ping probe.

Enable

When off, the default ping probe passes

IPv4 Primary Server

IPv4 Secondary Server

IPv6 Primary Server

IPv6 Secondary Server

Interval  s

Retry Interval  s

Timeout  s

Max Retries

- Go to **Status > Cellular** to check the status of the cellular connection. If modem status is ready and network status shows **Connected**, the SIM has been dialed up successfully.

Network	
Status	Connected
IPv4 Address	10.21.123.198/29
IPv4 Gateway	10.21.123.197
IPv4 DNS	112.5.230.54
IPv6 Address	2409:8934:2294:acfe::1/128
IPv6 Gateway	fe80::2
IPv6 DNS	2409:8034:2000::3
Connection Duration	0days, 00:08:06

## Related Topic

[Cellular Setting](#)

[Cellular Status](#)



## 6.2 Configure Ethernet Connection

UF51 CPE supports getting network access via WAN port.

### Configuration Steps

1. Go to **Network > Interface > Interface** page, find the WAN interface and click **Edit** button.

The screenshot shows the 'Interface' configuration page in the Milesight web interface. The left sidebar is expanded to 'Network', and 'Interface' is selected. The main content area displays three interfaces: WAN, LAN, and Cellular. Each interface has a 'RESTART' and 'EDIT' button. The WAN interface's 'EDIT' button is highlighted with a red box.

2. Select the protocol according to your network CPE mode or network provider types and configure the corresponding parameters, then save all settings.

- **DHCP:** upper network router will assign an IP address to UF51 WAN port. This is the easiest way and requires the upper route to enable the DHCP server.
- **Status Address:** assign a static IP address with the same subnet as the LAN subnet of the upper network router. Besides, it's necessary to configure at least one DNS server.
- **PPPoE:** type your PPPoE account username and password, this should contact your network provider.

Protocol	Static Address
IP Type	Static Address
IPv4 Address	192.168.40.204
IPv4 Netmask	255.255.255.0
IPv4 Gateway	192.168.40.1
IPv4 Primary DNS	114.114.114.114
IPv4 Secondary DNS	8.8.8.8

3. Go to **Network > Interface > Link Failover** to enable WAN and drag the button to change link priority.

Interface Interface Setting **Link Failover** Static IP Address Assignment

### Link Priority

Link failover enables the device to switch to the next link automatically following the order of the priority list when it detects that the current link is unavailable. Tables from top to bottom, priority from high to low

Priority	Enable Rule	Link in Use	Interface	Connection Type	IP	
1	<input checked="" type="checkbox"/>	<span style="color: gray;">●</span>	Cellular	DHCP Client	-	<input type="button" value="EDIT"/>
2	<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	WAN	Static Address	192.168.40.48	<input type="button" value="EDIT"/>

4. Click **Edit** of a link to configure ICMP ping detection information. When ping probe is enabled, the router will send ICMP packets to detection server to check if this link is valid. If no response and exceeding max retries, it will switch to the lower priority link.

**Note:** if you use private network, please change a private server address or disable the ping probe.

Enable

When off, the default ping probe passes

IPv4 Primary Server

IPv4 Secondary Server

IPv6 Primary Server

IPv6 Secondary Server

Interval  s

Retry Interval  s

Timeout  s

Max Retries

5. Click **Network > Diagnostics** to check the network connectivity.

### Diagnostics

Execution of various network commands to check the connection and name resolution to other systems.

```

PING www.google.com (142.250.207.68): 56 data bytes
64 bytes from 142.250.207.68: seq=0 ttl=117 time=28.484 ms
64 bytes from 142.250.207.68: seq=1 ttl=117 time=28.222 ms
64 bytes from 142.250.207.68: seq=2 ttl=117 time=29.495 ms
64 bytes from 142.250.207.68: seq=3 ttl=117 time=29.827 ms
64 bytes from 142.250.207.68: seq=4 ttl=117 time=29.340 ms

--- www.google.com ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 28.222/29.073/29.827 ms

```

## Related Topic

[WAN Setting](#)

## 6.3 Configure Wi-Fi Access Point

UF51 CPE supports both 2.4G and 5G Wi-Fi and they can work as access points to provide network access to other devices at the same time. We are about to take an example of configuring a 2.4G Wi-Fi access point.

### Configuration Steps

1. Ensure the Wi-Fi antennas are connected to the correct connectors.
2. Go to **Network > WLAN** page to enable 2.4G Wi-Fi mode, then users can modify the radio type, SSID and other parameters. For security access, it's suggested to select an encryption mode and define a key for devices to connect to Wi-Fi.

The screenshot shows the configuration page for WLAN1-2.4G. The settings are as follows:

- Enable:
- Type: AP
- BSSID: 00:0c:43:26:46:44
- Radio Type: 802.11bgn/ax mixed
- Channel: Auto
- Bandwidth: 40 MHz
- SSID: 111UR75v3-2.4G
- Encryption Mode: WPA-PSK/WPA2-PSK
- Cipher: AES/TKIP
- Key: .....
- Group Rekey Interval: 3600 s

3. Use a smart phone to connect the access point of UF51. You can check the information of the connected client/user on **Status > Overview** page.

Active DHCP Leases			
Hostname	IPv4-Address	MAC-Address	Remaining Lease Time
HUAWEI_P20-9c88dbba544dae	192.168.1.147	C4:9F:4C:64:B3:B7	22h 35m 12s
ANA-AN00	192.168.1.119	D2:17:2E:4D:C0:BB	20h 34m 20s

### Related Topic

[WLAN Setting](#)

## 6.4 Configure PPTP Client

### Example



Configure the UF51 as PPTP client to connect to a PPTP server in order to have data transferred securely. Refer to the following topological graph.

### Configuration Steps

1. Go to **VPN > PPTP**, configure PPTP server IP address, username and password provided by PPTP server.

**Note:** if you want to have all data transferred through VPN tunnel, check **Global Traffic Forwarding** option.

PPTP

PPTP\_1

Enable

Remote IP Address

Username

Password

Authentication Type

Global Traffic Forwarding

Remote Subnet

Remote Subnet Mask

Advanced Settings

If you want to access peer subnet such as 192.168.3.0/24, you need to configure the subnet and mask to add the device.

Remote Subnet

Remote Subnet Mask

2. Check **Advanced Settings** option, and you will see the advance settings.

Advanced Settings

Local IP Address

Peer IP Address

MPPE

Address/Control Compression

Protocol Field Compression

Asyncmap Value

MRU

MTU

Link Detection Interval  s

Max Retries

Expert Options

If the PPTP server assigns fixed tunnel IP to the client, then you can fill in the local tunnel IP and remote tunnel IP, shown as below.

Local IP Address

Peer IP Address

Otherwise PPTP server will assign tunnel IP randomly.

Click **Save** button when you complete all settings, and then the advanced settings will be hidden again. Then click **Apply** button to have configurations take effect.

3. Go to **Status > VPN** and check PPTP connection status.

PPTP is established as shown below.

**Local IP:** the client tunnel IP.

**Remote IP:** the server tunnel IP.

VPN			
Clients			
Name	Status	Local IP	Remote IP
pptp_1	Connected	192.40.48.1	192.11.30.1
pptp_3	Connected	192.10.44.10	192.10.44.1
l2tp_1	Connected	192.40.48.1	192.168.10.17

## Related Topics


[PPTP](#)

[PPTP Status](#)

## 6.5 Configure NAT Rule

### Example

An UF51 CPE can access to the Internet via cellular and get a public IP address. LAN port is connected with an IP camera whose IP address is 192.168.23.165 and HTTP port is 80. This IP camera can be accessed by public IP address via the below port mapping settings.




### Configuration Steps

Go to **Network > Firewall > Port Mapping** and configure port mapping parameters as below. External IP address 0.0.0.0/0 means all external addresses are allowed to access. After that, users can use public IP: external port to access the IP camera.

**Port Mapping(DNAT)**

When external services are needed internally (for example, when a website is published externally), the external address initiates an active connection. And, the router or the gateway on the firewall receives the connection. Then it will convert the connection to the internal. This conversion is called DNAT, which is mainly used for external and internal services.  
List Priority: The priority is lowered in accordance with the table from top to bottom.

Name	Protocol	External IP Address	External Port	Internal IP Address	Internal Port	Enable	
Camera	TCP/UDP	0.0.0.0/0	45	192.168.23.165	80	<input checked="" type="checkbox"/>	<input type="button" value="DELETE"/>




### Related Topic

[Port Mapping](#)

## 6.6 Configure Serial DTU Connection

### Example

A PLC is connected with the UF51 via RS232 and need to transfer the data to a remote TCP server transparently.



### Configuration Steps

- Go to **Industrial > Serial Port**, enable Serial 1 and configure serial port parameters. The serial port parameter shall be kept in consistency with those of PLC, as shown in figure below.

- Configure Serial Mode as **DTU Mode** and protocol as **TCP Client**.

- Configure TCP server IP and port.


Destination IP Address

Server Address	Server Port	Status	
110.87.98.58	7087	Disconnected	<div style="float: right;"> <span style="background-color: red; color: white; padding: 2px 5px;">DELETE</span>   <span style="background-color: blue; color: white; padding: 2px 5px;">ADD</span> </div>

- Start TCP server on PC. Take **Netassist** test software as example. Make sure port mapping is done.




- Connect the UF51 to PC via RS232 for PLC simulation. Then start **sscom** software on the PC to test communication through serial port.




- After connection is established between the UF51 and the TCP server, you can send data between sscom and Netassist.

**PC side**



**TCP server side**





7. After serial communication test is done, you can connect PLC to RS232 port of the UF51 for test.


## Related Topic

[Serial Port](#)


## 6.7 Restore Factory Defaults

### Method 1:

Go to **System > Backup/Upgrade** page, click **Perform Reset** button, you will be asked to confirm if you'd like to reset it to factory defaults. Then click **OK** button.



Then the device will reboot and restore to factory settings immediately.



Please wait till the STATUS LED shines in green, which means the device has already been reset to factory defaults successfully.

## Related Topic

[Backup / Flash Firmware](#)

## Method 2:

Locate the reset button on the CPE, press and hold the reset button for more than 5s until the LED blinks.

## 6.8 Firmware Upgrade


It is suggested that you contact Milesight technical support first before you upgrade the device. After getting the image file please refer to the following steps to complete the upgrade.

1. Go to **System > Backup/Upgrade** page, and click **Flash image...**

The screenshot shows the Milesight web interface. On the left is a navigation menu with 'System' selected. The main content area is divided into two sections:

- Restore:** Contains instructions to upload a backup archive and a 'PERFORM RESET' button. A note states: 'Custom files (certificates, scripts) may remain on the system. To prevent this, perform a factory-reset first.'
- Flash new firmware image:** Contains instructions to upload a firmware image and a 'FLASH IMAGE...' button.

2. Browse the correct firmware file from the PC, click **Upload** and the device will check if the firmware file is correct. If it's correct, the firmware will be imported to the device.



3. After upload, click **Continue** to upgrade the device. When SYS LED changes from orange to green and stay statically, the upgrade is completed. Do not perform any operation or disconnect the

power during the upgrade.

**Flash image?** ✕

The flash mirror image was uploaded. The listed information below is the checksum and file size, compare them with the original file to ensure data integrity. Click "Proceed" below to start the flash procedure.

- Size: 65.20 MB
- MD5: cc6a14d668da29ba48eea5b114859eb1
- SHA256: 01d9ff1e431bd818513e99c4aa4e58004e2084bddcc09a8ac79b052530db149a

KEEP CURRENT CONFIGURATION

CANCEL
CONTINUE

**Flashing...**

The system is flashing now.  
**DO NOT POWER OFF THE DEVICE!**  
 Wait a few minutes until you try to reconnect. It might be necessary to renew the address of your computer to reach the device again, depending on your settings.

## Related Topic

[Backup / Flash Firmware](#)

# Chapter 7 Web Configuration

## 7.1 Status

### 7.1.1 Overview

The System tab contains the basic information of the router on this page.

Status	
<b>System</b>	
Hostname	Router
Model	UF51-504AE-W
SN	6905C1786844
Firmware Version	30.0.0.1-a2-sdk18-base
Hardware Version	V1.0
Local Time	2023-01-29 05:33:32
Uptime	16d 17h 58m 36s
Average Load	2.09, 2.05, 2.01

System	
Item	Description
Hostname	The hostname of device, it can be modified on <b>System &gt; System &gt; General Settings</b> .
Model	The model name of the device.
SN	The serial number of the device.
Firmware Version	The current firmware version of the device.
Hardware Version	The current hardware version of the device.
Local Time	The current system time of the device , it can be modified on <b>System &gt; System &gt; General Settings</b> .
Uptime	The time since the device has been powered and running.
Load Average	Averages over progressively longer periods of time (1, 5 and 15 minutes averages), the smaller numbers are better.

## Memory

Available Memory

422.30 MB / 651.02 MB (65%)

Remaining Memory

228.72 MB / 651.02 MB (35%)


Memory	
Item	Description
Available Memory	The available memory and memory utilization of the device.
Used	Show the memory used and the utilization of the device.

The **Current Network** tab displays the basic information of link in use, click Interface chapter for details.

### Current Network

- Accessible IP address of the Internet

Cellular



**Current SIM:** SIM2


- **IPv4:** 10.21.123.198/29
- **IPv6:** 2409:8934:2294:acfe::1/128

**Runtime:** 0h 19m 20s

### Current Network

- Accessible IP address of the Internet

WAN



**Type:** Static Address

- **IPv4:** 192.168.40.164
- IPv6:** -
- IPv4 Gateway:** 192.168.40.1
- IPv6 Gateway:** -
- MAC:** 24:E1:24:F5:AF:D2
- Runtime:** 14h 43m 16s

The Active DHCP Leases tab displays the basic information of connected devices.

## Active DHCP Leases

Hostname	IPv4-Address	MAC-Address	Remaining Lease Time
DESKTOP-DMKN66R	192.168.133.148	2C:16:DB:AE:43:2E	9h 21m 32s

Item	Description
<b>Active DHCP Leases</b>	
Hostname	The hostname of the connected device.
IPv4-Address	The IPv4 address of the connected device.
MAC-Address	The MAC address of the connected device.
Leasetime remaining	The time remaining for this lease.

## 7.1.2 Cellular

You can view the cellular network status of router on this page.

Cellular Status	
Status	Ready
Module Model	RG500L-EU
Version	RG500LEUACR04A01M8G_OCPU_20.001.20.001
Cellular Band	N41
Signal Strength	-68dBm
Register Status	Registered(Home network)
IMEI	869263050336332
IMSI	460028688541190
ICCID	89860016111591001190
ISP	CHINA MOBILE
Network Type	5G SA
PLMN ID	46000
LAC	3259E7
Cell ID	203959107

CQI	-
DL Bandwidth	100MHz
UL Bandwidth	100MHz
SINR	29.5dB
PCI	23F
RSRP	-68dBm
RSRQ	-11dB
EARFCN	7B49E

Modem Information	
Item	Description
Status	Corresponding detection status of module and SIM card.
Module Model	The model name of cellular module.
Version	The firmware version of cellular module.
Cellular Band	The cellular band which the router used to register to network.
Signal Strength	The RSSI (Received Signal Indicator ) of registered cellular network.
Register Status	The registration status of SIM card.
IMEI	The IMEI of the cellular module.
IMSI	The IMSI of the SIM card.
ICCID	The ICCID of the SIM card.
ISP	The network provider which the SIM card registers on.
Network Type	The connected network type, such as LTE, 3G, etc.
PLMN ID	The current PLMN ID, including MCC, MNC, LAC and Cell ID.
LAC	The location area code of the SIM card.
Cell ID	The Cell ID of the SIM card location.
CQI	The Channel Quality Indicator of the cellular network.
DL Bandwidth	The DL bandwidth of the cellular network.
UL Bandwidth	The UL bandwidth of the cellular network.
SINR	The Signal Interference + Noise Ratio of the cellular network.
PCI	The physical-layer cell identity of the cellular network.
RSRP	The Reference Signal Received Power of the cellular network.
RSRQ	The Reference Quality Received Power of the cellular network.
EARFCN	The E-UTRA Absolute Radio Frequency Channel Number.

## Network

Status	Connected
IPv4 Address	10.140.53.203/29
IPv4 Gateway	10.140.53.204
IPv4 DNS	218.85.152.99
IPv6 Address	240e:466:2168:245b::1/128
IPv6 Gateway	fe80::2
IPv6 DNS	240e:14:6000::1
Connection Duration	0days, 03:38:32

## Monthly Data Statistics

The traffic statistics here are for reference only, and the actual traffic is subject to the charging bill provided by the operator.

SIM-1	RX: 0.0 MiB	TX: 0.0 MiB	ALL: 0.0 MiB
SIM-2	RX: 22.1 MiB	TX: 6.0 MiB	ALL: 28.2 MiB

Network	
Item	Description
Status	The connection status of cellular network.
IPv4/IPv6 Address	The IPv4/IPv6 address and netmask of cellular network.
IPv4/IPv6 Gateway	The IPv4/IPv6 gateway and netmask of cellular network.
IPv4/IPv6 DNS	The DNS sever of cellular network.
Connection Duration	The information on how long the cellular network has been connected.
RX	The data volume and packets received of this month.
TX	The data volume and packets transmitted of this month.
ALL	Total data volume and packets of this month.

### 7.1.3 GPS

When GPS function is enabled and the GPS information is obtained successfully, you can view the latest GPS information including GPS time, latitude, longitude and speed on this page.

## GPS

## GPS Status

Status	Obtained
Time for Locating	2022/11/24 05:51:05
Satellites In Use	36
Satellites In View	71
Latitude	24.624043 N
Longitude	118.030530 E
Altitude	83.6 M
Speed	0.000000 km/h

GPS Status	
Item	Description
Status	The obtain status of GPS.
Time for Locating	The time for locating.
Satellites In Use	The quantity of satellites in use.
Satellites In View	The quantity of satellites in view.
Latitude	The Latitude of the location.
Longitude	The Longitude of the location.
Altitude	The Altitude of the location.
Speed	The speed of movement.

### 7.1.4 Firewall

On this page you can check all IPv4/IPv6 chains of iptables. Users can click the targets with dashed line to jump to the corresponding chains.



**Firewall Status**

**Table: Filter**

Chain *INPUT* (Policy: *ACCEPT*, 0 Packets, 0 B Traffic)

Pkts.	Traffic	Target	Prot.	In	Out	Source	Destination	Options	Remark
1.58 K	147.65 KB	ACCEPT	all	lo	*	0.0.0.0/0	0.0.0.0/0	-	-
15.90 K	3.61 MB	<a href="#">input_rule</a>	all	*	*	0.0.0.0/0	0.0.0.0/0	-	Custom input rule chain
5.06 K	951.37 KB	ACCEPT	all	*	*	0.0.0.0/0	0.0.0.0/0	ctstate RELATED,ESTABLISHED	-
131	6.81 KB	<a href="#">syn_flood</a>	tcp	*	*	0.0.0.0/0	0.0.0.0/0	tcp flags:0x17/0x02	-
10.84 K	2.66 MB	zone_wan_input	all	eth1	*	0.0.0.0/0	0.0.0.0/0	-	-
0	0 B	zone_lan_input	all	br-lan	*	0.0.0.0/0	0.0.0.0/0	-	-
0	0 B	zone_vlan3_input	all	a1	*	0.0.0.0/0	0.0.0.0/0	-	-
0	0 B	zone_vlan4_input	all	a2	*	0.0.0.0/0	0.0.0.0/0	-	-

[main status/overview](#)

Firewall Status	
Item	Description
Table: Filter	The default table for handing network packets.
Table: NAT	Used to alter packets that create a new connection and used for Network Address Translation (NAT).
Table: Mangle	Used for specific types of packet alternation.
Show/Hide Empty Chain	Show/hide the chain without any rule.
Reset Counts	Reset the traffic counts of all chains.
Restart Firewall	Restart the whole firewall process.

### 7.1.5 Routing Table

You can check routing status on this page, including the routing table and ARP cache.

**IPv4 Router**

Interface	Destination Network	IPv4 Gateway	Priority
wan	0.0.0.0/0	192.168.45.1	0
wan	0.0.0.0	192.168.45.1	0
wan	114.114.114.114	192.168.45.1	0
lan	192.168.1.0/24	-	0
wan	192.168.45.0/24	-	0

**ARP**

IPv4 Address	MAC Address	Interface
192.168.45.17	F8E4:38:53:86:6D	wan
192.168.45.1	B8E3:81:90:FD:01	wan
192.168.45.32	C85B:76:C1:89:59	wan

Active IPv6 Router			
Interface	Destination Network	IPv6 Gateway	Priority
lan	fd39:999a:bb32::/64	-	1024

IPv6 Neighbor		
IPv6 Address	MAC Address	Interface

Item	Description
<b>Active IPv4/IPv6 Routes</b>	
Interface	The outbound interface of the route.
Destination Network	The IP address and netmask of destination host or destination network.
IPv4/IPv6 Gateway	The IP address of the gateway to send packets from.
Priority	The metric number indicating interface priority of usage.
<b>ARP Cache</b>	
IPv4 Address	The IP address of ARP pool.
MAC Address	The IP address's corresponding MAC address.
Interface	The binding interface of ARP.
<b>IPv6 Neighbor</b>	
IPv6 Address	The IP address of neighbor.
MAC Address	The IP address's corresponding MAC address.
Interface	The binding interface of neighbor.

## 7.1.6 VPN

You can check VPN status on this page.

VPN			
<b>Clients</b>			
Name	Status	Local IP	Remote IP
ipsec_1	Connected	172.16.63.32/27	10.255.11.0/24
<b>IPsec Server</b>			
Status	Server IP	Connected Clients IP	<i>This section contains no values now.</i>
<b>OpenVPN Server</b>			
Status	Server IP	Connected Clients IP	<i>This section contains no values now.</i>

VPN Status	
Item	Description
<b>Clients</b>	
Name	The name of the enabled VPN clients.

Status	The connection status of client.
Local IP	The local IP address and subnet of the VPN tunnel.
Remote IP	The real remote IP address and subnet of the VPN tunnel.
<b>IPsec/OpenVPN Server</b>	
Status	The status of Server.
Server IP	The server IP address and subnet of the VPN tunnel.
Connected Clients IP	The IP address of the client which is connected to the server.

## 7.2 Network

### 7.2.1 Interfaces

This menu allows to configure the basic settings of cellular, WAN and LAN interfaces.

**Interface**

<p><b>WAN</b></p> <p>📶</p>	<p>Uptime: 2h 32m 57s  MAC: 24:E1:24:F5:AC:FE  RX: 43.07 MB (366912 Pkts.)  TX: 27.66 MB (31466 Pkts.)  IPv4: 192.168.40.204/24</p>	<p>RESTART</p> <p>EDIT</p>
<p><b>LAN</b></p> <p>📶</p>	<p>Uptime: 2h 32m 50s  MAC: D2:B8:7D:56:E4:1C  RX: 80.16 KB (902 Pkts.)  TX: 46.40 KB (549 Pkts.)  IPv4: 192.168.1.1/24  IPv6: fd0b:2786:8e2a:0:d0b8:7dff:fe56:e41c/64</p>	<p>RESTART</p> <p>EDIT</p>
<p><b>Cellular</b></p> <p>📶</p>	<p>RX: 0 B (0 Pkts.)  TX: 0 B (0 Pkts.)</p>	<p>RESTART</p> <p>EDIT</p>

Interfaces	
Item	Description
Restart	Click to restart this network interface.
Edit	Click to edit general settings of this network interface.

**Global Network Option**

IPv6 ULA-Prefix

Global Network Options	
Item	Description
IPv6 ULA-Prefix	The IPv6 unique local address (ULA) prefix of this device.

#### 7.2.1.1 WAN

The WAN port can be connected with an Ethernet cable to get Internet access. It supports 3 connection types which can work with both IPv4 and IPv6.

- **Static IP:** configure IPv4 address, netmask and gateway for Ethernet WAN interface.
- **DHCP Client:** configure Ethernet WAN interface as DHCP Client to obtain IPv4 address automatically.
- **PPPoE:** configure Ethernet WAN interface as PPPoE or PPPoEv6 Client.

General Setting

Advanced Setting

Status



Uptime: 2h 33m 47s

MAC: 24:E1:24:F5:AC:FE

RX: 43.20 MB (367448 Pkts.)

TX: 28.38 MB (32148 Pkts.)

IPv4: 192.168.40.204/24

WAN - Status	
Item	Description
Uptime	How long has the device been running.
MAC	MAC address of WAN interface.
RX	RX: the data volume and packets received in this interface.
TX	TX: the data volume and packets transmitted from this interface.
IPv4	IPv4 address of WAN interface.

## 1. Static IP Configuration

If the external network assigns a fixed IP for the WAN interface, please select this mode.

Protocol

IP Type

IPv4 Address

IPv4 Netmask

IPv4 Gateway

IPv4 Primary DNS

IPv4 Secondary DNS

Static Address - General Settings		
Item	Description	Default
IP Type	It's fixed as IPv4.	IPv4
IPv4 Address	Set the IPv4 address of the WAN port.	--
IPv4 Netmask	Set the Netmask for WAN port.	255.255.255.0
IPv4 Gateway	Set the gateway for WAN port's IPv4 address.	--
IPv4 Primary DNS	Set the primary IPv4 DNS server.	114.114.114.114
IPv4 Secondary DNS	Set the secondary IPv4 DNS server.	8.8.8.8

General Setting

Advanced Setting

MTU **Static Address - Advanced Settings**

Item	Description
MTU	Set the maximum transmission unit. Range: 68-1500.

**2. DHCP Client**

If the external network has DHCP server enabled and has assigned IP addresses to the Ethernet WAN interface, please select this mode to obtain IP address automatically.

General Setting

Advanced Setting

Status

Uptime: 2h 35m 52s

MAC: 24:E1:24:F5:AC:FE

RX: 44.10 MB (376615 Pkts.)

TX: 30.27 MB (33873 Pkts.)

IPv4: 192.168.40.204/24

Protocol

DHCP Client

**DHCP Client - Advanced Settings**

Item	Description
Obtain DNS server automatically	Obtain peer DNS automatically, DNS is necessary when visiting domain name.
MTU	Set the maximum transmission unit. Range: 68-1500.

**3. PPPoE/PPPoEv6**

PPPoE refers to a point to point protocol over Ethernet. If IPv6 negotiation is enabled, router can get both IPv4 and IPv6 address.

General Setting

Advanced Setting

Status

Uptime: 2h 37m 52s

MAC: 24:E1:24:F5:AC:FE

RX: 44.30 MB (378298 Pkts.)

TX: 31.43 MB (34778 Pkts.)

IPv4: 192.168.40.204/24

Protocol

PPPoE

PAP/CHAP Username

PAP/CHAP Password

### PPPoE - General Settings

Item	Description
PAP/CHAP Username	Enter the username provided by your Internet Service Provider (ISP).
PAP/CHAP Password	Enter the password provided by your Internet Service Provider (ISP).

General Setting

Advanced Setting

Obtain IPv6-Address 

Enable IPv6 negotiation on the PPP link

Obtain DNS server automatically Max Retries Heartbeat Interval  sMTU 

### PPPoE - Advanced Settings

Item	Description
Obtain IPv6-Address	Enable IPv6 negotiation on the PPP link.
Obtain DNS server automatically	Obtain peer DNS automatically during PPP dialing. DNS is necessary when visiting domain name.
Max Retries	Set the maximum retry times after it fails to dial up. Range: 0-9.
Heartbeat Interval (s)	Set the heartbeat interval for link detection. Range: 1-600.
MTU	Set the maximum transmission unit. Range: 68-1500.

## Related Configuration Example

### [Ethernet WAN Connection](#)

#### 7.2.1.2 LAN/DHCP Server

General Setting

Advanced Setting

DHCP Server

Status  Uptime: 2h 39m 0s

MAC: D2:B8:7D:56:E4:1C

RX: 80.16 KB (902 Pkts.)

TX: 47.72 KB (561 Pkts.)

IPv4: 192.168.1.1/24

IPv6: fd0b:2786:8e2a:0:d0b8:7dff:fe56:e41c/64

IPv4 Address IPv4 Netmask IPv6 Prefix Length 

Assign the given length part of every public IPv6-prefix to this interface

IPv6 Prefix Identifier 

Assign the prefix part of this hexadecimal sub ID to this interface.

LAN - General Settings	
Item	Description
Status	<b>Uptime:</b> how long has the device been running.
	<b>MAC:</b> MAC address of LAN interfaces.
	<b>RX:</b> the data volume and packets received in this interface.
	<b>TX:</b> the data volume and packets transmitted from this interface.
	<b>IPv4/IPv6:</b> IPv4/IPv6 address of LAN interfaces.
IPv4 Address	Set the IPv4 address of LAN interface.
IPv4 Netmask	Set the netmask for LAN interface.
IPv6 Prefix Length	Assign a part of given length of every public IPv6-prefix to this interface.
IPv6 Prefix Identifier	Assign prefix parts using this hexadecimal sub-prefix ID for this interface.

General Setting

Advanced Setting

DHCP Server

MTU 1500

LAN - Advanced Settings	
Item	Description
MTU	Set the maximum transmission unit. Range: 68-1500.

## General Setup

Enable 

Start Address 192.168.1.100

End Address 192.168.1.199

IPv4 Lease Time 1440 m

IPv4 Netmask 255.255.255.0

DNS Server 192.168.1.1 

DHCP Server-General Setup	
Item	Description
Enable	Enable to disable DHCP for this interface.
Start Address	Define the beginning of the pool of IP addresses which will be leased to DHCP clients.
End Address	Define the end of the pool of IP addresses which will be leased to DHCP clients.
IPv4 Lease time	Set the expiry time of leased addresses, the minimum is 2 minutes (2m).

IPv4-Netmask	Set to override the netmask sent to clients. Normally it is calculated from the subnet that is served.
DNS Server	Set the DNS server list for clients.

**IPv6 Settings**

Enable

Router Announcement Service Server Mode

DHCPv6 Service Server Mode

DHCPv6 Mode Stateless


Announced DNS Servers  +

DHCP Server-IPv6 Settings	
Item	Description
Enable	Choose to enable DHCPv6 server when using cellular IPv6 or PPPoE v6.
Router Advertisement Service	It's fixed as server mode.
DHCPv6 Service	It's fixed as server mode.
DHCPv6 Mode	It's fixed as stateless mode.
Announced DNS Servers	Set the DNS server list for clients.

**7.2.1.3 Cellular**

IP Type

APN

PIN  

Authentication Type

Network Type

Roaming

MTU

Data Limit  MB

Billing Day

Cellular Band  
 5G NR Band:  
 N1, N3, N5, N7, N8, N20, N28, N38, N40, N41, N77, N78  
 LTE Band:  
 B1, B3, B5, B7, B8, B20, B28, B32, B38, B40, B41, B42, B43



Cellular - General Settings	
Item	Description
IP Type	Show the Internet protocol type to use for this interface. Option: IPv4, IPv6 and IPv4/IPv6.
APN	Enter the Access Point Name for cellular dial-up connection provided by local ISP.
PIN	Enter a 4-8 characters PIN code to unlock the SIM.
Authentication Type	Select from NONE, PAP, CHAP and PAP/CHAP.
Network Type	Select from Auto, 5G Only, 4G Only and 3G Only. Auto: connect to the network with the strongest signal automatically. 5G Only: connect to 5G network only. And so on.
Roaming	Enable or disable roaming.
MTU	Set the maximum transmission unit. Range: 68-1500.
Data Limit	Set the data limit of this month. If data traffic exceeds this limit, this SIM card will be forbidden to use this month. The default is blank (no limited).
Billing Day	Clear the monthly data statistics when reaching the billing day of this month.
Cellular Band	Select the 5G NR and 4G LTE bands used to register to cellular network. This can be used to optimize cellular speeds by selecting specific bands.

## Related Application

[Cellular Application](#)

### 7.2.1.4 Interface Settings

UF51 5G CPE supports 2 Gigabit Ethernet ports. This page display the properties of all Ethernet ports and allows to control the status of these ports.

Interface Setting

Interface	Status	Property	Interface Speed	Interface Mode
LAN1/WAN	Up	WAN	Auto	Auto
LAN2	Up	LAN	Auto	Auto

Interface Setting	
Item	Description
Interface	Users can define the Ethernet ports according to their needs.
Status	Set the status of Ethernet port; select <b>Up</b> to enable and <b>Down</b> to disable.
Property	The Ethernet port's type as a WAN port or a LAN port.
Interface Speed	Ethernet port speed is fixed as Auto.


Interface Mode	Ethernet port mode is fixed as Auto.
----------------	--------------------------------------

### 7.2.1.5 Link Failover

This section describes how to configure link failover strategies, their priority and the ping settings, each rule owns its ping rules by default. UF51 will follow the priority to choose the next available interface to access the internet, make sure you have enabled the full interface that you need to use here. If priority 1 can only use IPv4, UF51 will select a second link in which IPv6 works as the main IPv6 link and vice versa.

#### Link Priority

Link failover enables the device to switch to the next link automatically following the order of the priority list when it detects that the current link is unavailable. Tables from top to bottom, priority from high to low

Priority	Enable Rule	Link in Use	Interface	Connection Type	IP	
1	<input checked="" type="checkbox"/>	<span style="color: grey;">●</span>	Cellular	DHCP Client	-	 <a href="#">EDIT</a>
2	<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	WAN	Static Address	192.168.43.32	 <a href="#">EDIT</a>

#### Settings


Revert to High Priority Link

After checking, it will periodically detect whether the higher priority link is available. If a higher priority link is available, it will switch to the link with a higher priority.

Revert Interval  s

Emergency Reboot

After enabling, if all interfaces are unavailable, the system will reboot.

Link Failover	
Item	Description
<b>Link Priority</b>	
Priority	Display the priority of each interface, you can modify it by the operation's <b>up</b> and <b>down</b> button.
Enable Rule	If enabled, the router will choose this interface into its switching rule. For the Cellular interface, if it's not enabled here, the interface will be disabled as well.
Link in Use	Mark whether this interface is in use with Green color.
Interface	Display the name of the interface.
Connection type	Display how to obtain the IP address in this interface, like static IP or DHCP. For cellular interface, it only supports as DHCP Client.
IP	Display the IP address of the interface.
	Drag this button to adjust the priority of network links. The top of the list has the highest priority.
Edit	Click to edit ping probe settings of every network link.
<b>Settings</b>	
Revert to high	When enabled, periodically detect whether the high-priority link can be

priority link	pinged, and if so, switch the link with a higher priority.
Revert Interval	Specify the number of seconds that you should wait for switching to the link with higher priority, range: 1 - 21600s.
Emergency Reboot	Enable to reboot the device if not any link is available.

## Ping Probe

Enable 

When off, the default ping probe passes

IPv4 Primary Server IPv4 Secondary Server IPv6 Primary Server IPv6 Secondary Server Interval  sRetry Interval  sTimeout  sMax Retries 

Ping Probe	
Item	Description
Enable	If enabled, the router will periodically detect the connection status of the link by sending ICMP packets.
IPv4/IPv6 Primary Server	The router will send ICMP packet to the IPv4/IPv6 address to determine whether the network connection is still available or not.
IPv4/IPv6 Secondary Server	The router will try to ping the alternative server address if primary server is not available.
Interval	Time interval (in seconds) between two Pings.
Retry Interval	Set the ping retry interval. When ping failed, the router will ping again in every retry interval.
Timeout	The maximum amount of time the router will wait for a response to a ping request. If it does not receive a response for the amount of time predefined in this field, the ping request will be considered as fail.
Max Retries	The retry times of the router sending ping request until determining that the connection has failed.

### 7.2.1.6 Static IP Address Assignment

When LAN interface works as DHCP server, user can assign fixed IP addresses and symbolic hostnames to devices with fixed MAC addresses.

#### Static IP Address Assignment

Static leases are used to assign fixed IP addresses and symbolic hostnames to DHCP clients. It can be connected by the assigned host via the interface with a non-dynamic configuration. Add new lease items with Add Button. The address and the value of the hostname field will be assigned to the host identified by the MAC address field. The tenancy term, an optional field, is able to set the duration of DHCP tenancy term for every host individually.

Hostname	MAC Address	IPv4 Address	IPv4 Lease Time
<i>This section contains no values now.</i>			

[ADD](#)

Static IP Address Assignment	
Item	Description
Hostname	The hostname of static leases.
MAC Address	The MAC address of the DHCP client.
IPv4 Address	The IPv4 address assigned to the client.
IPv4 Lease time	Time remaining for the client.

### 7.2.2 WLAN (Wi-Fi Version Only)

This section explains how to set the related parameters for Wi-Fi network. UF51 supports both 2.4G and 5G Wi-Fi and they can work at the same time.

WLAN1-2.4G
WLAN2-5G

Enable

Type AP

BSSID 00:0c:43:26:d6:44

Radio Type 802.11bgn/ax mixed

Channel Auto

Bandwidth 40 MHz

SSID 111UR75v3-2.4G

Encryption Mode No Encryption

SSID Broadcast

AP Isolation

Max Client Number 128

MAC Filtering

Type Whitelist

MAC Address	Description
<i>This section contains no values now.</i>	

WLAN	
Item	Description
Enable	Enable/disable WLAN.
Type	The work type is fixed as AP.

BSSID	The MAC address of the access point.
Radio Type	Select radio type.
Channel	Select wireless channel from 1 to 13 or select Auto.
Bandwidth	Select bandwidth. The options are 20MHz and 40MHz.
SSID	Define the SSID of the access point.
Encryption Mode	Select encryption mode. The options are No Encryption, WEP Open System , WEP Auto, WEP Shared Key, WPA-PSK, WPA2-PSK, WPA3-PSK, WPA-PSK/WPA2-PSK and WPA2-PSK/WPA3-PSK.
Cipher	Select cipher when using PSK type encryption mode. The options are AES, TKIP and AES/TKIP.
Key	Define the key of access point.
Group Rekey Interval	The interval of changing the cipher key.
SSID Broadcast	When SSID broadcast is disabled, other wireless devices can't find the SSID, and users have to enter the SSID manually to access to the wireless network.
AP Isolation	When AP isolation is enabled, all users that access to the AP are isolated without communicating with each other.
Max Client Number	Type the max client number that the access point supports, range: 1-128.
<b>MAC Filtering</b>	
MAC Filtering	Enable or disable the filter of Wi-Fi client MAC addresses.
Type	<b>Whitelist:</b> Only the listed MAC addresses are allowed to connect to the router's wireless access point. <b>Blacklist:</b> The listed MAC addresses are not allowed to connect to the router's wireless access point.

## Related Topic

[Wi-Fi Application Example](#)

## 7.2.3 Firewall

This section describes how to set the firewall parameters, including security, ACL, DMZ, Port Mapping and custom iptables rules. After setting, users can go to **Status > Firewall** to check if firewall settings work.

### 7.2.3.1 General Settings

## Security Configuration

Enable SYN-flood protection Log in via HTTPS by default 

## Access Control

Name	Port	Local Access	Remote Access
HTTP	80	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
HTTPS	443	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
SSH	999	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
TELNET	23	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

## URL Filter

Domain Name Keyword Filter

baidu Please enter the keyword in th... 

Example: To filter www.google.com, enter google.

General Setting		
Item	Description	Default
<b>Security Configuration</b>		
Enable SYN-flood Protection	Enable/disable SYN-flood protection. SYN-flood protection allows to protect from a DDoS attack that exploits part of the normal TCP three-way handshake to consume resources on the targeted server and render it unresponsive.	Enable
Log in using HTTPS by default	Log in the web GUI of device via HTTPS by default.	Enable
<b>Access Control</b>		
Port	Set port number of the services. Range: 1-65535.	--
Local Access	Access the router locally.	Enable
Remote Access	Access the router remotely.	Disable
HTTP	Users can log in the device locally via HTTP to access and control it through Web after the option is checked.	80
HTTPS	Users can log in the device locally and remotely via HTTPS to access and control it through Web after the option is checked.	443
TELNET	Users can log in the device locally and remotely via Telnet after the option is checked.	23
SSH	Users can log in the device locally and remotely via SSH after the option is checked.	22
<b>URL Filtering</b>		

Domain Name Keyword Filtering	You can block specific website by entering keyword from a domain name. After filtering, the devices under LAN ports can not access corresponding websites. The maximum number of characters allowed is 64.
----------------------------------	--

### 7.2.3.2 ACL

The access control list, also called ACL, implements permission or prohibition of access for specified network traffic (such as the source IP address) by configuring a series of matching rules so as to filter the network interface traffic. When a router receives a packet, the field will be analyzed according to the ACL rule applied to the current interface. After the special packet is identified, the permission or prohibition of corresponding packet will be implemented according to preset strategy. The data package matching rules defined by ACL can also be used by other functions requiring flow distinction.

ACL

Default Filter Policy:

Policy Priority: DMZ > DNAT > Access Service Control > ACL  
List Priority: The priority is lowered in accordance with the table from top to bottom.

Name	Match Rule	Action	Enable
Rule1	Forwarded IPv4, protocol TCP, UDP, ICMP From WAN(WAN, Cellular), IP 0.0.0.0/0 To LAN, IP 0.0.0.0/0	Accept forward	<input checked="" type="checkbox"/>

ACL	
Item	Description
Default Filter Policy	The packets which are not included in the access control list will be processed by the default filter policy. <b>Accept:</b> allow all traffic out of devices under LAN ports. <b>Drop:</b> deny all traffic out of devices under LAN ports.
Enable	Enable this ACL rule.
<input type="button" value="≡"/>	Drag this button to adjust the priority of ACL rules. The top of the list has the highest priority.
Edit	Click to edit the details of this ACL rule.
Delete	Delete this ACL rule.

Name	<input type="text" value="Rule1"/>
IP Type	<input type="text" value="IPv4"/>
Protocol	<input type="text" value="TCP"/> <input type="text" value="UDP"/> <input type="text" value="ICMP"/>
Source Interface	<input type="text" value="WAN(WAN, Cellular)"/>
Source Type	<input type="text" value="IP"/>
Source IP Address	<input type="text" value="0.0.0.0"/> Eg:192.168.1.1 or 192.168.1.1/24
Source port	<input type="text" value="Any Port"/> You can enter the port number, or enter 20-300
Destination Interface	<input type="text" value="LAN"/>
Destination IP Address	<input type="text" value="0.0.0.0"/> Eg:192.168.1.1 or 192.168.1.1/24
Destination port	<input type="text" value="Any Port"/> You can enter the port number, or enter 20-300
Action	<input type="text" value="Accept"/>

ACL - Add/Edit	
Name	Define a unique name for this ACL rule.
Type	Select type as IPv4 or IPv6.
Protocol	Select protocol among TCP, UDP and ICMP.
Source Interface	Select the source interface type from Device Output, LAN, VLAN or WAN (WAN, Cellular, WLAN). Device Output means the packets coming from router itself.
Source Type	When using IPv4 type, select the address type as IP, MAC or IP+MAC.
Source IP/MAC Address	Set source network address according to address type. (0.0.0.0/0 means all).
Source Port	Set specific source port number or port range, example: 20-300.
Destination Interface	Select the destination interface type from LAN, WAN (WAN, Cellular, WLAN),VLAN or Device Input. Device Input means the packets going to router itself.
Destination IP Address	Set destination network address (0.0.0.0/0 means all).
Destination Port	Set specific source port number or port range, example: 20-300.
Action	Select action as Accept or Drop.

### 7.2.3.3 Port Mapping (DNAT)

When external services are needed internally (for example, when a website is published externally), the external address initiates an active connection. And, the router or the gateway on the firewall receives the connection. Then it will convert the connection into the an internal connection. This conversion is called DNAT, which is mainly used for external and internal services.



**Port Mapping(DNAT)**

When external services are needed internally (for example, when a website is published externally), the external address initiates an active connection. And, the router or the gateway on the firewall receives the connection. Then it will convert the connection to the internal. This conversion is called DNAT, which is mainly used for external and internal services.

List Priority: The priority is lowered in accordance with the table from top to bottom.

Name	Protocol	External IP Address	External Port	Internal IP Address	Internal Port	Enable		
<input type="text"/>	TCP   UDP ▾	<input type="text" value="0.0.0.0/0"/>	<input type="text" value="80"/>	<input type="text" value="192.168.1.1"/>	<input type="text" value="80"/>	<input checked="" type="checkbox"/>	☰	DELETE
								ADD

Port Mapping (DNAT)	
Item	Description
Name	Define a unique name of the port mapping rule.
Protocol	Select TCP or UDP for your application requirements.
External IP Address	Specify the host or network which can access local IP address. 0.0.0.0/0 means all.
External Port	Set the port or port range from which incoming packets are forwarded, example: 20-300.
Internal IP Address	Enter the IP address that packets are forwarded to after receiving from the incoming interface.
Internal Port	Enter the port or port range that packets are forwarded to after receiving from the incoming port(s). When setting port range, the value should be the same as external port range.
Enable	Enable or disable this port mapping rule.
☰	Drag this button to adjust the priority of port mapping rules. The top of the list has the highest priority.
Delete	Delete this rule.

**Related Configuration Example**

[NAT Application Example](#)

**7.2.3.4 DMZ**

DMZ is a host within the internal network that has all ports exposed, except those forwarded ports in port mapping.

**DMZ**

The DMZ host is an intranet host whose ports are only open to the specific addresses except for the occupied and forwarded ports. After enabling DMZ, all data received from the source IP address by the router will be forwarded to the DMZ host IP address filled in.

Enable

DMZ Host

Source IP Address

DMZ	
Item	Description
Enable	Enable or disable DMZ.
DMZ Host	Enter the IP address of the DMZ host on the internal network.
Source IP Address	Set the source IP address which can access to DMZ host. "0.0.0.0/0" means any address.

### 7.2.3.5 Custom Rules

In this page, you can enter your own custom firewall iptables rules and these will get executed as a Linux shell script.

**Firewall - Custom Rules**

Custom rules allow you to execute the iptables commands of firewall. Note that the URL filtering command is invalid.

```
# This file is interpreted as shell script.
# Put your custom iptables rules here, they will
# be executed with each firewall (re-)start.

# Internal uci firewall chains are flushed and recreated on reload, so
# put custom rules into the root chains e.g. INPUT or FORWARD or into the
# special user chains, e.g. input_wan_rule or postrouting_lan_rule.
```

### 7.2.3.6 Certificates

In this page, you can import the HTTPS certificates for router web GUI secure access.

**HTTPS Certificate**

Certificate

Key

### 7.2.4 Static Routes

A static routing is a manually configured routing entry. Information about the routing is manually entered rather than obtained from dynamic routing traffic. After setting static routing, the package for the specified destination will be forwarded to the path designated by users.

### Static IPv4 Routes

Interface	Destination Network	IPv4 Netmask	IPv4 Gateway	Priority	MTU	
LAN	10.245.200.0	255.255.255.0	10.245.220.9	1	1500	<span style="color: red; border: 1px solid red; padding: 2px 5px;">DELETE</span> <span style="border: 1px solid #007bff; padding: 2px 5px; margin-top: 5px;">ADD</span>

---

### Static IPv6 Routes

Interface	Destination Network	IPv6 Gateway	Priority	MTU
<i>This section contains no values now.</i>				

ADD

Static Routes	
Item	Description
Interface	The interface allows the data to reach the destination address.
Destination Network	Enter the destination IPv4/IPv6 address.
IPv4 Netmask	Enter the subnet mask of IPv4 destination address.
IPv4/IPv6 Gateway	IPv4/IPv6 address of the next router that will be passed by before the input data reaches the destination address.
Priority	Smaller value refers to higher priority. Range: 1-255.
MTU	Set the maximum transmission unit. Range: 68-1500.

## 7.2.5 Diagnostics

Network Utilities includes IPv4/IPv6 ping, IPv4/IPv6 traceroute, nslookup the command-line tool.

### Diagnostics

Execution of various network commands to check the connection and name resolution to other systems.

IPv4 PING

IPv4 TRACEROUTE

NSLOOKUP

```

PING openwrt.org (139.59.209.225) data bytes
64 bytes from 139.59.209.225: seq=0 ttl=44 time=261.390 ms
64 bytes from 139.59.209.225: seq=1 ttl=44 time=264.242 ms
64 bytes from 139.59.209.225: seq=2 ttl=44 time=261.901 ms
64 bytes from 139.59.209.225: seq=3 ttl=44 time=260.720 ms
64 bytes from 139.59.209.225: seq=4 ttl=44 time=260.762 ms

--- openwrt.org ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 260.720/261.803/264.242 ms
                    
```

Network Utilities	
Item	Description
IPv4 Ping	Click to ping outer network from the device in IPv4.

IPv6 Ping	Click to ping outer network from the device in IPv6.
IPv4 Traceroute	Address of the destination host to be detected in IPv4.
IPv6 Traceroute	Address of the destination host to be detected in IPv6.
Nslookup	Click to obtain the mapping between domain name and IP address, or other DNS records.

## 7.3 VPN

Virtual Private Network, also called VPNs, are used to securely connect two private networks together so that devices can connect from one network to the other network via secure channels.

### 7.3.1 OpenVPN

OpenVPN is an open source virtual private network (VPN) product that offers a simplified security framework, modular network design, and cross-platform portability.

#### 7.3.1.1 OpenVPN Server

UF51 supports OpenVPN Server to create secure point-to-point or site-to-site connections in routed or bridged configurations and remote access facilities. You can import the ovpn file directly or configure the parameters on this page to set this server.

**OpenVPN Server**

Enable

Configuration Method

Configuration File  BROWSE EDIT EXPORT DELETE

OpenVPN Server - File Configuration	
Item	Description
Browse	Click to browser the server configuration ovpn format file including the settings and certificates. Please refer to the server configuration file according to sample: <a href="#">server.conf</a>
Edit	Click to edit the imported file.
Export	Export the server configuration file.
Delete	Click to delete the configuration file.

Configuration Method	<input type="text" value="Page Configuration"/>	▼
Protocol	<input type="text" value="UDP"/>	▼
Port	<input type="text" value="1194"/>	
Listening IP	<input type="text" value="1.1.1.1"/>	
Network Interface	<input type="text" value="tun"/>	▼
Authentication Type	<input type="text" value="None"/>	▼
Local Virtual IP	<input type="text" value="10.8.0.1"/>	
Remote Virtual IP	<input type="text" value="10.8.1.1"/>	
Compression	<input type="text" value="LZO"/>	▼
Ping Detection Interval	<input type="text" value="60"/>	s
Ping Detection Timeout	<input type="text" value="300"/>	s
Encryption Mode	<input type="text" value="None"/>	▼
MTU	<input type="text" value="1500"/>	
Max Frame Size	<input type="text" value="1500"/>	
Log Level	<input type="text" value="Notice"/>	▼
Expert Options	<input type="text"/>	

**Account**

Username	Password
<i>This section contains no values now.</i>	

[ADD ACCOUNT](#)

**Local Router**

Subnet	Subnet Mask
<i>This section contains no values now.</i>	

[ADD ROUTER](#)

**Client Subnet**

Name	Subnet	Subnet Mask
<i>This section contains no values now.</i>		

[ADD SUBNET](#)

OpenVPN Server - Page Configuration	
Item	Description
Protocol	Select a transport protocol used by connection from UDP and TCP.
Listening IP	Enter the local hostname or IP address for bind. If left blank, OpenVPN server will bind to all interfaces.
Port	Enter the TCP/UCP service number for OpenVPN client connection. Range: 1-65536.
Network Interface	Select virtual VPN network interface type from TUN and TAP. TUN devices encapsulate IPv4 or IPv6 (OSI Layer 3) while TAP devices encapsulate Ethernet 802.3 (OSI Layer 2).
Authentication Type	Select authentication type used to secure data sessions. <b>Pre-shared:</b> use the same secret key as server to complete the authentication. After select, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import a static.key to <b>PSK</b> field. <b>Username/Password:</b> use username/password which is preset in server side to complete the authentication. <b>X.509 cert:</b> use X.509 type certificate to complete the authentication. After select, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import CA certificate, client certificate and client private key to corresponding fields. <b>X.509 cert + user:</b> use both username/password and X.509 cert authentication type.
Local Virtual IP	Set local tunnel address when authentication type is <b>None</b> or <b>Pre-shared</b> .
Remote Virtual IP	Set remote tunnel address when authentication type is <b>None</b> or <b>Pre-shared</b> .
Client Subnet	Define an IP address pool for openVPN client.
Client Netmask	Set the client subnet netmask to limit the IP address range.
Renegotiation Interval	Renegotiation data channel key after this interval. 0 means disable.
Max Clients	Limit server to a maximum of concurrent clients, range: 1-128. <b>Note:</b> please adjust log severity to Info if you need to connect many clients.
Enable CRL	Enable or disable CEL verify.
Enable Client to Client	When enabled, openVPN clients can communicate with each other.
Enable Dup Client	Allow multiple clients to connect with the same common name or certification.
Enable TLS Authentication	Disable or enable TLS authentication when authentication type is X.509 cert. After being enabled, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import a ta.key to <b>TA</b> field. <b>Note:</b> this option only supports tls-auth. For tls-crypt, please add this format string on expert option: tls-crypt /etc/openvpn/openvpn-client1-ta.key
Compression	Select to enable or disable LZO to compress data.
Ping Detection Interval	Set link detection interval time to ensure tunnel connection. If this is set on both server and client, the value pushed from server will override the client local values. Range: 10-1080 s.

Ping Detection Timeout	OpenVPN will be reestablished after timeout. If this is set on both server and client, the value pushed from server will override the client local values. Range: 60-3600 s.
Encryption Mode	Select from NONE, BF-CBC, DES-CBC, DES-EDE3-CBC, AES-128-CBC, AES-192-CBC and AES-256-CBC.
MTU	Enter the maximum transmission unit. Range: 68-1500.
Max Frame Size	Set the maximum frame size. Range: 64-1500.
Verbose Level	Select from ERROR, WARING, NOTICE and DEBUG.
Expert Options	User can enter some initialization strings in this field and separate the strings with semicolon. <b>Example:</b> auth SHA256; key direction 1
<b>Account</b>	
Username & Password	Set username and password for OpenVPN client when authentication type is username/password.
<b>Local Router</b>	
Subnet	Set the local route's IP address.
Subnet Mask	Set the local route's netmask.
<b>Client Subnet</b>	
Name	Set the name as OpenVPN client certificate common name.
Subnet	Set the subnet of OpenVPN client.
Subnet Mask	Set the subnet netmask of OpenVPN client.

### 7.3.1.2 OpenVPN Client

UF51 supports running at most 3 OpenVPN clients at the same time. You can import the ovpn file directly or configure the parameters on this page to set clients.

**Client\_1**

Enable

Configuration Method

Configuration File

#### OpenVPN Client - File Configuration

Item	Description
Browse	Click to browse the client configuration ovpn format file including the settings and certificate contents. Please refer to the client configuration file according to sample: <a href="#">client.conf</a>
Edit	Click to edit the imported file.
Export	Export the server configuration file.
Delete	Click to delete the configuration file.

Configuration Method	<input type="text" value="Page Configuration"/>
Protocol	<input type="text" value="UDP"/>
Port	<input type="text" value="1194"/>
Remote Address	<input type="text" value="192.168.45.220"/>
Network Interface	<input type="text" value="tun"/>
Authentication Type	<input type="text" value="None"/>
Local Virtual IP	<input type="text"/>
Remote Virtual IP	<input type="text"/>
Compression	<input type="text" value="LZO"/>
Ping Detection Interval	<input type="text" value="60"/> s
Ping Detection Timeout	<input type="text" value="300"/> s
Encryption Mode	<input type="text" value="None"/>
MTU	<input type="text" value="1500"/>
Max Frame Size	<input type="text" value="1500"/>
Log Level	<input type="text" value="Notice"/>
Expert Options	<input type="text"/>

**Local Router**

Subnet	Subnet Mask
<i>This section contains no values now.</i>	

[ADD ROUTER](#)
**OpenVPN Client - Page Configuration**

Item	Description
Protocol	Select a transport protocol used by connecting UDP and TCP.
Remote IP Address	Enter remote OpenVPN server's IP address or domain name.
Port	Enter the TCP/UCP service number of remote OpenVPN server. Range: 1-65535.
Network Interface	Select virtual VPN network interface type from TUN and TAP. TUN devices encapsulate IPv4 or IPv6 (OSI Layer 3) while TAP devices encapsulate Ethernet 802.3 (OSI Layer 2).
Authentication Type	Select authentication type used to secure data sessions.



	<p><b>Pre-shared:</b> use the same secret key as server to complete the authentication. After selecting, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import a static.key to <b>PSK</b> field.</p> <p><b>Username/Password:</b> use username/password which is preset in server side to complete the authentication.</p> <p><b>X.509 cert:</b> use X.509 type certificate to complete the authentication. After selecting, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import CA certificate, client certificate and client private key to corresponding fields.</p> <p><b>X.509 cert + user:</b> use both username/password and X.509 cert authentication type.</p>
Local Virtual IP	Set local tunnel address when authentication type is <b>None</b> or <b>Pre-shared</b> .
Remote Virtual IP	Set remote tunnel address when authentication type is <b>None</b> or <b>Pre-shared</b> .
Global Traffic Forwarding	All the data traffic will be sent out via OpenVPN tunnel when this function is enabled.
Enable TLS Authentication	<p>Disable or enable TLS authentication when authentication type is X.509 cert. After being enabled, go to <b>VPN &gt; OpenVPN &gt; Certifications</b> page to import a ta.key to <b>TA</b> field.</p> <p><b>Note:</b> this option only supports tls-auth. For tls-crypt, please add this format string on expert option: <code>tls-crypt /etc/openvpn/openvpn-client1-ta.key</code></p>
Compression	Select to enable or disable LZO to compress data.
Ping Detection Interval	Set link detection interval time to ensure tunnel connection. If this is set on both server and client, the value pushed from server will override the client local values. Range: 10-1800 s.
Ping Detection Timeout	OpenVPN will be reestablished after timeout. If this is set on both server and client, the value pushed from server will override the client local values. Range: 60-3600 s.
Encryption Mode	Select from NONE, BF-CBC, DES-CBC, DES-EDE3-CBC, AES-128-CBC, AES-192-CBC and AES-256-CBC.
MTU	Enter the maximum transmission unit. Range: 128-1500.
Max Frame Size	Set the maximum frame size. Range: 128-1500.
Verbose Level	Select from ERROR, WARING, NOTICE and DEBUG.
Expert Options	<p>User can enter some initialization strings in this field and separate the strings with semicolon.</p> <p><b>Example:</b> <code>auth SHA256; key direction 1</code></p>
<b>Local Route</b>	
Subnet	Set the local route's IP address.
Subnet Mask	Set the local route's netmask.

### 7.3.1.3 Certificate

When using page configuration of OpenVPN server or client, users can import/export necessary certificate and key files to this page according to the authentication types.

### Server

CA Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Private key	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
DH	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
TA	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
CRL	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
PSK	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>

### Client\_1

CA Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Private key	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
TA	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
PSK	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>

## 7.3.2 IPsec

IPsec is especially useful for implementing virtual private networks and for remote user access through dial-up connection to private networks. A big advantage of IPsec is that security arrangements can be handled without requiring changes to individual computer.

IPsec provides three choices of security service: Authentication Header (AH), Encapsulating Security Payload (ESP), and Internet Key Exchange (IKE). Ah essentially allows authentication of the senders' data. ESP supports both authentications of the sender and data encryption. IKE is used for cipher code exchange. All of them can protect one and more data flows between hosts, between host and gateway, and between gateways.

### 7.3.2.1 IPSec Server

## IPsec Server

Enable	<input checked="" type="checkbox"/>
IPsec Mode	Tunnel
IPsec Protocol	ESP
Local Subnet	<input type="text"/>
Local Subnet Mask	<input type="text"/>
Local ID Type	Default
Remote Subnet	<input type="text"/>
Remote Subnet Mask	<input type="text"/>
Remote ID Type	Default
SA Encryption Algorithm	AES128
SA Authentication Algorithm	SHA1
PFS Group	NULL
SA Lifetime	3600 s
DPD Time Interval	30 s
DPD Timeout	150 s

IPsec Server	
Item	Description
Enable	Enable or disable IPsec server mode.
IPsec Mode	Select Tunnel or Transport.
IPsec Protocol	Select from ESP or AH.
Local Subnet	Enter the local LAN subnet IP address on the IPsec tunnel.
Local Subnet Netmask	Enter the local LAN netmask on the IPsec tunnel.
Local ID Type	Select the identifier type, and send it to remote peer. <b>Default:</b> None <b>ID:</b> use local subnet IP address as ID <b>FQDN:</b> fully qualified domain name, example: test.user.com <b>User FQDN:</b> fully qualified username string with email address format, example: test@user.com
Remote Subnet	Set the remote LAN subnet on the IPsec tunnel.
Remote Subnet Mask	Enter the remote LAN netmask on the IPsec tunnel.
Remote ID type	Select the identifier type that is the same as remote peer local ID. <b>Default:</b> None <b>ID:</b> use remote subnet IP address as ID

	<b>FQDN:</b> fully qualified domain name, example: test.user.com <b>User FQDN:</b> fully qualified username string with email address format, example: test@user.com
SA Encryption Algorithm	Select AES128, AES192 or AES256.
SA Authentication Algorithm	Select SHA1 or SHA2-256.
PFS Group	Select NULL, MODP768_1 , MODP1024_2 or MODP1536_5.
SA Lifetime	Set the lifetime of IPsec SA. Range: 60-86400 s.
DPD Interval Time	Set DPD retry interval to send DPD requests. Range: 2-60 s
DPD Timeout	When using IKE V1, set DPD timeout to detect the remote side fails. Range: 10-3600s.

IKE Parameter

IKE Version

Negotiation Mode

Encryption Algorithm

Authentication Algorithm

DH Group

Local Authentication

XAUTH

Lifetime  s

**PSK List**

Selector	PSK
<i>This section contains no values now.</i>	

IPsec Advanced

Expert Options

IKE Parameter	
Item	Description
IKE Version	Select the method of key exchange from IKEv1 and IKEv2.
Negotiation Mode	When using IKEv1, select Main or Aggressive.
Encryption Algorithm	Select DES, 3DES, AES128, AES192 or AES256.
Authentication Algorithm	Select MD5, SHA1 or SHA2-256.
DH Group	Select MODP768_1, MODP1024_2 or MODP1536_5.
Local Authentication	Select PSK or CA. <b>PSK:</b> use pre-shared key to complete the authentication. <b>CA:</b> use certificate to complete the authentication. After selecting, go to <b>VPN &gt; IPsec &gt; Certifications</b> page to import CA certificate, local certificate and private key to corresponding fields.
Remote Authentication	When using IKEv2, select PSK or CA. <b>PSK:</b> use pre-shared key to complete the authentication.

	<b>CA:</b> use certificate to complete the authentication.
XAUTH	When using IKEv1, define XAUTH username and password after XAUTH is enabled.
Lifetime	Set the lifetime in IKE negotiation. Range: 60-86400 s.
<b>XAUTH List</b>	
Username	Define the username used for the client xauth authentication.
Password	Define the password used for the client xauth authentication.
<b>PSK List</b>	
Selector	Set the selector as IP address or local ID of IPsec client. If it is left blank, all clients can use this PSK to complete authentication.
PSK	Define the pre-shared key.
<b>IPsec Advanced</b>	
Enable Compression	The head of IP packet will be compressed after it's enabled.
Margintime	Set advanced time before the lifetime expires to begin the re-negotiation.
Expert Options	User can enter some other initialization strings in this field to add extra settings and separate the strings with semicolon.

### 7.3.2.2 IPsec Client

UF51 supports running at most 3 IPsec clients at the same time.

#### IPsec\_1

Enable

IPsec Gateway Address

IPsec Mode

IPsec Protocol

Local Subnet

Local Subnet Mask

Remote ID Type

SA Encryption Algorithm

SA Authentication Algorithm

PFS Group

SA Lifetime  s

DPD Time Interval  s

DPD Timeout  s

#### IPsec Client

Item	Description
Enable	Enable or disable IPsec client mode. A maximum of 3 tunnels is allowed.
IP Gateway Address	Enter the remote IPsec server address.
IPsec Mode	Select Tunnel or Transport.
IPsec Protocol	Select ESP or AH.
Local Subnet	Enter the local LAN subnet IP address on the IPsec tunnel.
Local Subnet Netmask	Enter the local LAN netmask on the IPsec tunnel.
Local ID Type	Select the identifier type to send to remote peer. <b>Default:</b> None <b>ID:</b> use local subnet IP address as ID <b>FQDN:</b> fully qualified domain name, example: test.user.com <b>User FQDN:</b> fully qualified username string with email address format, example:test@user.com
Remote Subnet	Set the remote LAN subnet that on the IPsec tunnel.
Remote Subnet Mask	Enter the remote LAN netmask on the IPsec tunnel.
Remote ID type	Select the identifier type that is the same as remote peer local ID. <b>Default:</b> None <b>ID:</b> use remote subnet IP address as ID <b>FQDN:</b> fully qualified domain name, example: test.user.com <b>User FQDN:</b> fully qualified username string with email address format, example: test@user.com
SA Encryption Algorithm	Select AES128, AES192 or AES256.
SA Authentication Algorithm	Select SHA1 or SHA2-256.
PFS Group	Select NULL, MODP768_1 , MODP1024_2 or MODP1536_5.
SA Lifetime	Set the lifetime of IPsec SA. Range: 60-86400 s.
DPD Interval Time	Set DPD retry interval to send DPD requests. Range: 2-60 s
DPD Timeout	When using IKEv1, set DPD timeout to detect the remote side fails. Range: 10-3600 s.

IKE Parameter

IKE Version

Negotiation Mode

Encryption Algorithm

Authentication Algorithm

DH Group

Local Authentication

Local Secret Key

XAUTH

Lifetime  s

IPsec Advanced

Enable Compression

Margintime  s

Expert Options

IKE Parameter	
Item	Description
IKE Version	Select the method of key exchange of IKEv1 or IKEv2.
Negotiation Mode	When using IKEv1, select Main or Aggressive.
Encryption Algorithm	Select DES, 3DES, AES128, AES192 or AES256.
Authentication Algorithm	Select MD5, SHA1 or SHA2-256.
DH Group	Select MODP768_1, MODP1024_2 or MODP1536_5.
Local Authentication	Select PSK or CA. <b>PSK:</b> use pre-shared key to complete the authentication. <b>CA:</b> use certificate to complete the authentication. After selecting, go to <b>VPN &gt; IPsec &gt; Certifications</b> page to import CA certificate, local certificate and private key to corresponding fields.
Local Secret Key	Enter the pre-shared key which is defined on server side.
Remote Authentication	Select PSK or CA. <b>PSK:</b> use pre-shared key to complete the authentication. <b>CA:</b> use certificate to complete the authentication.
Remote Key	Enter the pre-shared key which is defined on server side.
XAUTH	When using IKEv1, define XAUTH username and password after

	XAUTH is enabled.
Lifetime	Set the lifetime in IKE negotiation. Range: 60-86400 s.
<b>IPsec Advanced</b>	
Enable Compression	The head of IP packet will be compressed after it's enabled.
Time Margintime	Set advanced time before the lifetime expires to begin the re-negotiation.
Expert Options	User can enter some other initialization strings in this field to add extra settings and separate the strings with semicolon.

### 7.3.2.3 Certificate

When using local authentication of IPsec server or client as CA, user can import/export necessary certificate and key files to this page.

**IPsec Server**

CA Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Local Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Private key	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>

**IPsec\_1**

CA Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Local Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Remote Certificate	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>
Private key	<input type="text"/>	<input type="button" value="BROWSE"/>	<input type="button" value="EXPORT"/>	<input type="button" value="DELETE"/>

### 7.3.3 L2TP

Layer Two Tunneling Protocol(L2TP) is an extension of the Point-to-Point Tunneling Protocol (PPTP) used by an Internet service provider (ISP) to enable the operation of a virtual private network (VPN) over the Internet.





## L2TP\_1

Enable

Server IP Address

Username


Password  

Authentication Type  

Global Traffic Forwarding

Remote Subnet

Remote Subnet Mask

Tunnel Key  

Advanced Setting

Local IP Address

Peer IP Address

Address/Control Compression

Protocol Field Compression

Asyncmap Value

MRU

MTU

Link Detection Interval  s

Expert Options

L2TP	
Item	Description
Enable	Enable or disable L2TP client.
Server IP Address	Enter remote L2TP server's IP address or domain name.
Username	Enter the username that L2TP server provides.
Password	Enter the password that L2TP server provides.
Authentication Type	Select authentication type used to secure data sessions.
Global Traffic Forwarding	All the data traffic will be sent out via L2TP VPN tunnel when this function is enabled.
Remote Subnet	Enter the remote subnet of L2TP VPN server.

Remote Subnet Mask	Enter the remote netmask of L2TP VPN server.
Tunnel Key	Enter the password of L2TP tunnel.
Local IP Address	Set tunnel IP address of L2TP client. Client will obtain tunnel IP address automatically from the server when it's null.
Peer IP Address	Enter tunnel IP address of L2TP server.
Enable MPPE	Enable or disable MPPE(Microsoft Point to Point Encryption).
Address/Control Compression	For PPP initialization. User can keep the default option.
Protocol Field Compression	For PPP initialization. User can keep the default option.
Asyncmap Value	One of the L2TP initialization strings. User can keep the default value. Range: 0-ffffff
MRU	Set the maximum receive unit. Range: 64-1500.
MTU	Set the maximum transmission unit. Range: 68-1500.
Link Detection Interval	Set the link detection interval time to ensure tunnel connection. Range: 0-600.
Export Options	Ter some initialization strings in this field and separate the strings with semicolon.

### 7.3.4 PPTP


Point-to-point Tunneling Protocol (PPTP) is a protocol that uses a TCP control channel and a Generic Routing Encapsulation tunnel to encapsulation PPP packets.


**PPTP\_1**

Enable

Server IP Address

Username

Password  

Authentication Type  

Global Traffic Forwarding

Remote Subnet

Remote Subnet Mask

Advanced Setting Local IP Address Peer IP Address Enable MPPE Address/Control Compression Protocol Field Compression Asyncmap Value MRU MTU Link Detection Interval  sMax Retries Expert Options 

PPTP	
Item	Description
Enable	Enable or disable PPTP client.
Server IP Address	Enter remote PPTP server's IP address or domain name.
Username	Enter the username that PPTP server provides.
Password	Enter the password that PPTP server provides.
Authentication Type	Select authentication type used to secure data sessions.
Global Traffic Forwarding	All the data traffic will be sent out via PPTP VPN tunnel when this function is enabled.
Remote Subnet	Enter the remote subnet of PPTP VPN server.
Remote Subnet Mask	Enter the remote netmask of PPTP VPN server.
Local IP Address	Set tunnel IP address of PPTP client. Client will obtain tunnel IP address automatically from the server when it's null.
Peer IP Address	Enter tunnel IP address of PPTP server.
Enable MPPE	Enable MPPE(Microsoft Point to Point Encryption).
Address/Control Compression	For PPP initialization. User can keep the default option.
Protocol Field Compression	For PPP initialization. User can keep the default option.
Asyncmap Value	One of the PPTP initialization strings. User can keep the default value. Range: 0-ffffff.
MRU	Set the maximum receive unit. Range: 64-1440.
MTU	Set the maximum transmission unit. Range: 68-1440.
Link Detection Interval	Set the link detection interval time to ensure tunnel connection. Range:

	0-600.
Max Retries	Set the maximum times of retrying to detect the PPTP connection failure. Range: 0-10.
Export Options	User can enter some initialization strings in this field and separate the string with semicolon.

### Related Configuration Example

[PPTP Client Application Example](#)

## 7.4 Industrial Interface

UF51 is capable of connecting with terminals through industrial interfaces so as to realize wireless communication between terminals and remote data centers.

There are two types of the router's industrial interface: serial port (RS485 or RS232) and I/O (digital input and digital output).

RS232 adopts full-duplex communication. It's generally used for communication within 20m.

RS485 adopts half-duplex communication to achieve transmission of serial communication data with distance up to 120m.

Digital input of I/O interface is a logical variable or switch variable with only two values of 0 and 1. 0 refers to a low level and 1 refers to a high level.

### 7.4.1 Serial Port

This section explains how to configure serial port parameters to achieve communication with serial terminals, and configure work mode to achieve communication with the remote data centers, so as to achieve two-way communication between serial terminals and remote data centers.

Serial 1

---

Enable

Serial Type RS485 ▼

Baud Rate 9600 ▼

Data Bits 8 Bits ▼

Stop Bits 1 Bits ▼

Parity None ▼

Software Flow Control

Serial Mode Modbus Master ▼

#### Serial Setting

Item	Description	Default
Enable	Enable or disable serial port function.	Disable
Serial Type	It is fixed as RS485 by default. If you want RS232 port, please contact sales before ordering. .	RS485
Baud Rate	The range is 300-230400. Same with the baud rate of the connected terminal device.	9600
Data Bits	8 bits or 7 bits optional. Same with the data bits of the connected terminal device.	8
Stop Bits	1 bit or 2 bits optional. Same with the stop bits of the connected terminal device.	1
Parity	Options are None, Odd and Even. Same with the parity of the connected terminal device.	None
Software Flow Control	Enable or disable software flow control.	Disable
Serial Mode	Select work mode of the serial port. <b>DTU Mode:</b> In DTU mode, the serial port can establish communication with the remote server/client. <b>GPS:</b> In GPS mode, go to <b>Industrial &gt; GPS &gt; GPS Serial Forwarding</b> to configure basic parameters to send GPS data to serial port. <b>Modbus Master:</b> In Modbus Master mode, go to <b>Industrial &gt; Modbus Master</b> to configure basic parameters and channels.	Disable

Serial Mode

DTU Protocol

Keepalive Interval  s

Keepalive Retry Times

Reconnect Interval  s

Specific Protocol

Packet Size  Byte

Serial Frame Interval  ms

Register String

**Destination IP Address**

Server Address	Server Port	Status
This section contains no values now.		

ADD

DTU Mode		
Item	Description	Default
DTU Protocol	Select from below protocols: <b>TCP Client:</b> the router is used as TCP client and transmits data to TCP server transparently. <b>UDP Client:</b> the router is used as UDP client and transmits data to	--

	<p>UDP server transparently.</p> <p><b>TCP server:</b> the router is used as TCP server to wait for polling data.</p> <p><b>UDP server:</b> the router is used as UDP server to wait for polling data.</p> <p><b>Modbus:</b> the router will be used as Modbus gateway, which can achieve conversion between Modbus RTU and Modbus TCP.</p>	
<b>TCP/UDP Server</b>		
Local port	Set the local port of this TCP/UDP server. Range: 1-65535.	502
Keepalive Interval	After TCP connection is established, client will send heartbeat packet regularly by TCP to keep alive. The interval range is 1-3600 s.	75
Max Retries	When TCP heartbeat times out, router will resend heartbeat. After it reaches the limitation of the preset retry times, TCP connection will be reestablished. The retry times range is 1-16.	9
Packet Size	Set the size of the serial data frame. Packet will be sent out when preset frame size reaches the limitation. The size range is 1-1024 byte.	1024
Serial Frame Interval	<p>The interval that the router sends out real serial data stored in the buffer area to public network. The range is 10-65535 ms.</p> <p><b>Note:</b> data will be sent out to public network when real serial data size reaches the preset packet size, even though it's within the serial frame interval.</p>	100
<b>TCP/UDP Client</b>		
Keepalive Interval	After TCP client is connected with TCP server, the client will send heartbeat packet by TCP regularly to keep alive. The interval range is 1-3600 s.	75
Keepalive Retry Times	When TCP heartbeat times run out, the router will resend heartbeat. After it reaches the preset retry times, router will reconnect to TCP server. The range is 1-16.	9
Reconnect Interval	When connection fails, router will reconnect to the server at the preset interval. The range is 10-60 s.	10
Specific Protocol	With Specific Protocol, the router will be able to connect to the TCP2COM software.	Disable
Heartbeat Interval	With Specific Protocol, the router will send heartbeat packet to the server regularly to keep alive. The interval range is 1-3600s.	30
ID	Define unique ID of each router. No longer than 63 characters and do not contain space character.	--
Packet Size	Set the size of the serial data frame. Packet will be sent out when preset frame size is reached. The range is 1-1024 byte.	1024
Serial Frame Interval	<p>The interval that the router sends out real serial data stored in the buffer area to public network. The range is 10-65535 ms.</p> <p><b>Note:</b> data will be sent out to public network when real serial data size reaches the preset packet size, even though it's within the serial frame interval.</p>	100
Register String	When setting UDP client, define register string for connection with the server.	Null

Server Address	Fill in the TCP or UDP server address (IP/domain name).	Null
Server Port	Fill in the TCP or UDP server port. Range: 1-65535.	Null
Status	Show the connection status between the router and the server.	--
<b>Modbus</b>		
Local Port	Set the router listening port. Range: 1-65535.	502
Max TCP Clients	Specify the maximum number of TCP clients allowed to connect the router which act as a TCP server.	32
Connection Timeout	If the TCP server does not receive any data from the slave device within the connection timeout period, the TCP connection will be broken.	60
Read Interval	Set the interval for reading remote channels. When a read cycle ends, the new read cycle begins until this interval expires. If it is set to 0, the device will restart the new read cycle after all channels have been read.	100
Response Timeout	Set the maximum response time that the router waits for the response to the command. If the device does not get a response after the maximum response time, it's determined that the command has run out of time.	3000
Max Retries	Set the maximum retry times after it fails to read.	3

## Related Configuration Example

[DTU Application Example](#)

## 7.4.2 I/O

### 7.4.2.1 DI

This section explains how to configure monitoring condition on digital input, and take certain actions once the conditions is reached.

Enable

Mode High Level ▾

Duration 100 ms

Action  DO

DI	
Item	Description
Enable	Enable or disable DI.
Mode	Select the working mode of DI. <b>High Level:</b> when it detects high level, trigger the action. <b>Low Level:</b> when it detects low level, trigger the action. <b>Counter:</b> when it detects a pulse, the counter value will increase by 1.

Duration (ms)	When the mode is high/low level, set the continuous duration of high/low level. Range: 1-10000.
Trigger Condition	When mode is counter, select the counter trigger condition. <b>Low-&gt;High:</b> The counter value will increase by 1 if digital input's status changes from low level to high level. <b>High-&gt;Low:</b> The counter value will increase by 1 if digital input's status changes from high level to low level.
Trigger Counter	The system will take actions accordingly when the counter value reach the preset one, and then reset the counter value to 0. Range: 1-100.
Action	Select the corresponding actions that the system will take when digital input mode meets the preset condition or duration. <b>DO:</b> Control output status of DO.

### 7.4.2.2 DO

This section describe how to configure digital output mode.

Enable

Mode

Initial Status

Duration of High Level  \*10 ms

Duration of Low Level  \*10 ms

The Number of Pulse

DO	
Item	Description
Enable	Enable or disable DO.
Mode	Select the working mode of DO. <b>High Level:</b> trigger the DO to send high level signal. <b>Low Level:</b> trigger the DO to send low level signal. <b>Counter:</b> trigger the DO to send pulses.
Initial Status	Select high level or low level as the initial status of the pulse.
Duration of High Level (*10ms)	Set the duration of pulse's high level. Range: 1-10000.
Duration of Low Level (*10ms)	Set the duration of pulse's low level. Range: 1-10000.
The Number of Pulse	Set the quantity of pulse. Range: 1-100.

### 7.4.3 Modbus Master



UF51 CPE can be set as Modbus RTU/TCP Master to poll the remote Modbus Slave and send data to TCP server.

### 7.4.3.1 Modbus Master

You can configure Modbus Master's parameters on this page.

Modbus Master		
Item	Description	Default
Enable	Enable/disable Modbus master.	--
Read Interval	Set the interval for reading remote channels. When the read cycle ends, the commands which haven't been sent out will be discard, and the new read cycle begins. If it is set as 0, the device will restart the new read cycle after all channels have been read. Range: 0-600 s.	0
Max Retries	Set the maximum retry times when it fails to read, range: 0-5.	3
Max Response Time	Set the maximum response time that the router waits for the response to the command. If the device does not get a response after the maximum response time, it's determined that the command has run out of time. Range: 10-1000 ms.	500
Execution Interval	The execution interval between each command. Range: 10-1000 ms.	50
Channel Name	Select a readable channel form <b>Industrial &gt; Channel &gt; Channel Setting.</b>	--

### 7.4.3.2 Channel

You can add the channels and configure alarm settings on this page, so as to connect the CPE to the remote Modbus Slave to pool the address on this page and receive alarms from the CPE in different conditions.

## Channel Setting

Name	Slave ID	Register Address	Number	Command Type	Link Type	Remote Device IP	Port	Sign	Decimal Place
Channel1	1	0	1	Holding Register	TCP			<input type="checkbox"/>	0

DELETE

ADD

## Channel Setting

Item	Description
Name	Set the name to identify the remote channel. It cannot be blank.
Slave ID	Set Modbus slave ID.
Address	The starting address for Modbus reading.
Number	The reading quantity from starting address.
Command Type	Read command data type, options are Coil, Discrete, Holding Register (INT16), Input Register (INT16), Holding Register (INT32) and Holding Register (Float).
Link Type	Select serial port or TCP connection. <b>Serial Port:</b> the router communicate with devices via Modbus RTU protocol. <b>TCP:</b> the router communicate with devices via Modbus TCP protocol.
Remote Device IP	When link is TCP, fill in the IP address of the remote Modbus TCP device.
Port	When link is TCP, fill in the port of the remote Modbus TCP device.
Sign	When command data type is holding register or input register, enable or disable to identify whether this channel is signed.
Decimal Place	When command data type is holding register or input register, indicate a dot in the read into the position of the channel. For example: read the channel value is 1234 and a Decimal Place is equal to 2, then the actual value is 12.34.

## TCP Forwarding

Name	IP	Port
Channel1		

DELETE

ADD

## TCP Forwarding

Item	Description
Name	The name of Modbus Master's channel.
IP	The IP address of the server to which the packets are forwarded .
Port	The port of the server's to which the packets are forwarded.

## 7.4.4 GPS

User can enable GPS feature here. For more debug information, please also enable GPS log.

GPS   GPS IP Forwarding   GPS Serial Forwarding

Enable

Enable GPS Log

### 7.4.4.1 GPS IP Forwarding

GPS IP forwarding means that GPS data can be forwarded over the Internet.

Enable

Type

Protocol

GPS Keepalive Interval  s

Keepalive Retry

Reconnect Interval  s

Report Interval  s

Stable Report Interval  s

Stable Decision Threshold  m

Include RMC Message

Include GSA Message

Include GGA Message

Include GSV Message

Include VTG Message

Message Prefix

Message Suffix

GPS IP Forwarding		
Item	Description	Default
Enable	Forward the GPS data to the client or server.	Disable
Type	Select connection type of the router as Client or Server.	Client
Protocol	Select protocol of data transmission as TCP or UDP.	TCP
GPS Keepalive Interval	When it's connected with server/client, the device will send heartbeat packet regularly to the server/client to keep alive. The interval range is 1-3600s.	75

Keepalive Retry	When TCP heartbeat times run out, the router will resend heartbeat. After it reaches the preset retry times, router will reconnect to TCP server. The range is 1-16.	9
Local Port	Set the router listening port when using as a Server. Range: 1-65535.	
Reconnect Interval	When the connection fails, router will reconnect to the server at the preset interval. The range is 10-60 s.	10
Report Interval	The device will send GPS data to the server/client according to this interval if it reaches the stable decision threshold. The range is 1-65535 s.	30
Stable Report Interval	The device will send GPS data to the server/client according to this interval if it does not reach the stable decision threshold. The range is 1-65535 s.	120
Stable Decision Threshold	The GPS location deviation within this distance can be regarded as no change. The range is 1-65535 m.	25
Include RMC Message	RMC includes time, date, position, course and speed data.	Enable
Include GSA Message	GSA includes GPS receiver operating mode, satellites used in the position solution, and DOP values.	Enable
Include GGA Message	GGA includes time, position and fix type data.	Enable
Include GSV Message	GSV includes the number, elevation, azimuth of GPS satellites and SNR values.	Enable
Include VTG Message	VTG includes course and speed information relative to the ground.	Enable
Message Prefix	Add a prefix to the GPS data.	Null
Message Suffix	Add a suffix to the GPS data.	Null
<b>Destination Address</b>		
Server Address	Fill in the server address to receive GPS data (IP/domain name).	--
Server Port	Fill in the server port to receive GPS data. Range: 1-65535.	--
Status	Show the connection status between the router and the server.	--

#### 7.4.4.2 GPS Serial Forwarding

GPS serial forwarding means that GPS data can be forwarded to the serial port.

GPS   GPS IP Forwarding   **GPS Serial Forwarding**

Enable

Serial Type

Report Interval  s

Include RMC Message

Include GSA Message

Include GGA Message

Include GSV Message

Include VTG Message

GPS Serial Forwarding		
Item	Description	Default
Enable	Forward the GPS data to the preset serial port.	Disable
Serial Type	Select the serial port to receive GPS data. Ensure that the serial port is enabled on <b>Industrial &gt; Serial Port</b> .	--
Report Interval	The device will forward the GPS data to the serial port according to this interval. The range is 1-65535s.	30
Include RMC Message	RMC includes time, date, position, course and speed data.	Enable
Include GSA Message	GSA includes GPS receiver operating mode, satellites used in the position solution, and DOP values.	Enable
Include GGA Message	GGA includes time, position and fix type data.	Enable
Include GSV Message	GSV includes the number, elevation, azimuth of GPS satellites and SNR values.	Enable
Include VTG Message	VTG includes course and speed information relative to the ground.	Enable

## 7.5 System

This section describes how to configure general settings and debugs, such as administration account, system time, common user management, download log, etc.

## 7.5.1 System

General Setting
NTP Setting

Hostname

Local Time 2023/03/28 00:57:51

Timezone  ▼

Time Synchronization  ▼

Set Time  🗓

System - General Setting	
Item	Description
Hostname	Define the device name, needs to start with a letter.
Local Time	Show the current system time.
Timezone	Click the drop-down list to select the time zone you are in.
Time Synchronization	Select the time synchronization mode. <b>Sync Browser Time:</b> Synchronize time with browser. <b>Sync with NTP Server:</b> Synchronize time with NTP Server. <b>GPS Time Synchronization:</b> Synchronize time with GPS per hour. Ensure that GPS is enabled on <b>Industrial &gt; GPS &gt;GPS</b> . <b>Manual:</b> configure the time manually.

General Setting
NTP Setting

Provide NTP server

NTP server candidates

×

×

×

+

System - NTP Setting	
Item	Description
Provide NTP server	Enable to provide NTP server for connected devices.
NTP server candidates	Enter NTP Server's IP address or domain name to synchronize time. It can add 5 servers at most.

## 7.5.2 Password

You can change the administration password for accessing the device.

**Password**

Changes the administrator password for accessing the device

Username

Old Password

New Password

Confirmation

Password	
Item	Description
Username	It's fixed as admin.
Old Password	Enter the old password to verify the authority.
New Password	Enter a new password.
Confirmation	Enter the new password again.

## 7.5.3 Device Management

### 7.5.3.1 Device Management

You can connect device to the Milesight DeviceHub management platform on this page so as to manage the device centrally and remotely. For more details, please refer to [DeviceHub User Guide](#).

**Device Management**

Status Disconnected

Server Address

Activation Method

Account name

Password

Device Management	
Item	Description

Status	Show the connection status between the device and the DeviceHub.
Server Address	IP address or domain of the DeviceHub management server.
Activation Method	Select activation method to connect the device to the DeviceHub server, options are " <b>By Authentication Code</b> " and " <b>By Account name</b> ".
Authentication Code	Fill in the authentication code generated from the DeviceHub.
Account Name	Fill in the registered DeviceHub account (email) and password.
Password	
Connect/Disconnect	Click this button to connect/disconnect the device from the DeviceHub.

### 7.5.3.2 Cloud VPN

You can connect the device to the MilesightVPN on this page so as to manage the CPE and connected devices centrally and remotely. For more details please refer to [MilesightVPN User Guide](#).

**Settings**

Server

Port

Authentication Code

Device Name

**Status**

Status Disconnected

Local IP --

Remote IP --

Connection Time --

Cloud VPN	
Item	Description
<b>Settings</b>	
Server	Enter the IP address or domain name of MilesightVPN.
Port	Enter the HTTPS port number.
Authorization code	Enter the authorization code which generated by MilesightVPN.
Device Name	Enter the name of the device.
<b>Status</b>	
Status	Show the connection information about whether the router is



	connected to the MilesightVPN.
Local IP	Show the virtual IP of the router.
Remote IP	Show the virtual IP of the Milesight VPN server.
Connection Time	Show the information on how long has the router been connected to the Milesight VPN.

### 7.5.4 Backup / Upgrade

This section describes how to create a complete backup of the system configurations to a file, reset to factory defaults, restore the config file to the device and upgrade the flash image via the web. Generally, you don't need to do the firmware upgrade.

**Note:** any operation on web page is not allowed during firmware upgrade, otherwise the upgrade will be interrupted, or worse the device will break down.

**Backup**

Click "Generate Backup" to download a tar archive of the current configuration files.

Download backup

---

**Restore**

You can upload a previously generated backup archive here to restore configuration files. Click "Perform Reset" if you want to reset the firmware to its initial state.

Reset

Restore Backup

Custom files (certificates, scripts) may remain on the system. To prevent this, perform a factory-reset first.

---

**Flash new firmware image**

Upload a image here to replace the running firmware.

Firmware Image

Backup/Upgrade	
Item	Description
Generate Backup	Click to download a tar archive of the current configuration file.
Perform Reset	Click to reset the device to factory default.
Upload Archive...	To restore configuration files, you can upload a previously generated backup archive here. Custom files (certificates, scripts) may remain on the system. To prevent this, you can perform a factory-reset first.
Flash Image...	Upload an image here to replace the running firmware.

### Related Configuration Example

[Firmware Upgrade](#)

[Restore Factory Defaults](#)

## 7.5.5 Reboot

This page allows to reboot the device immediately or regularly.


Reboot	
Item	Description
Reboot Now	Reboot the device immediately.
Schedule	
Enable	Click to enable reboot schedule.
Cycles	Reboot the device at a scheduled frequency.
Time	Select the time to execute the schedule.

## 7.5.6 Log

Users can download logs contains a record of informational, error and warning events that indicates how the system processes. BY reviewing the data in the log, an administrator or user troubleshooting the system can identify the cause of a problem or whether the system processes are loading successfully. Remote log server is feasible, and the device will upload all system logs to remote log server such as Syslog Watcher.

Log Control - General Settings	
Item	Description

External system log server	Fill in the remote log server address (IP/domain name) which the router sends.
External system log server port	Fill in the remote log server port which the router sends.
External system log server protocol	Choose UDP or TCP from the drop-down list to transmit log file in corresponding protocol.
Cron Log Level	The severities to print the AP log: Normal, Warning, Debug.
AP Log	Select to start or stop recording system log.
Start or Stop MD Log	Select to start or stop recording cellular module log.
MD Log Save Mode	Select the save and output mode of MD log.
MD Log Level	The severities to print the MD log: Info, Notice, Warning, Error, Critical, Alert, Emergency, Debug.



Log Control - Advanced Settings	
Item	Description
<b>AP log</b>	
Download	Click to download the last AP log recorded.
<b>Tcpdump log</b>	
Start	Click to start recording tcpdump log.
Stop	Click to stop recording tcpdump log.
Download	Click to download the last tcpdump log recorded.

## 7.5.7 Debugger

### 7.5.7.1 Cellular Debugger

This tool allows to use AT commands to check cellular debug information. You can press the buttons on the top of black frame directly to execute common commands directly or enter the AT command that you want to send to cellular modem and press **Enter** to execute.

Cellular Debugger Firewall Debugger

Enter the AT command that you want to send to cellular modem. Press "Enter" to execute.

Eg: AT+COPS?

AT+CSQ AT+ECELL AT+ERAT? AT+EPBSEH? AT+CREG? AT+COPS?

CLEAR

**Common command description:**

AT+CSQ?---Get cellular network signal

AT+ECELL?---Get current cell information

AT+ERAT?---Get RAT status and network type

AT+EPBSEH? ---Get using bands

AT+CREG?---Get network registration status

AT+COPS?---Get operator and access technology info

**7.5.7.2 Firewall Debugger**

This tool allows to use iptables commands to check firewall information and download results.

Cellular Debugger Firewall Debugger

Command

Eg: -t nat -nvL INPUT

CLEAR DOWNLOAD

[END]